

IBM-PC/XT

培训上机实例集

(修订本)

李玉林 编

科海培训中心

一九八八年三月

目 录

一、硬件系统	(1)
1.1 PCTEST测试盘使用	(1)
1.2 RS232联机通迅实习	(5)
文件传送	(6)
联机对话	(7)
1.3 打印机字型设定	(9)
FONT.BAS 16字型设定程序	(12)
二、PC DOS 2.00系统	(12)
2.1 EDLIN—文本建立	(12)
2.2 Autoexec.BAT批命令执行文件	(13)
1) EDLIN命令或COPY CON: Autoexec.bat建立	(13)
2) 批命令运行过程	(13)
2.3 分级目录—建立和显示	(16)
2.4 DEBUG命令	(17)
1) 内存查找	(18)
2) DEBUG机内码修改	(20)
三、PC汇编与宏汇编样板程序	(22)
3.1 汇编与宏汇编及源程序的汇编操作	(22)
1) 小汇编	(22)
2) 宏汇编	(28)
3.2 汇编源程序小例题	(35)
1) 屏幕显示255个字符	(35)
2) 乐曲发声	(37)
3) 计时工资程序	(39)
四、BASIC, BASICA	(45)
4.1 文件处理	(45)
1) 顺序文件	(45)
2) 随机文件	(46)
4.2 BASIC调用汇编子程序	(48)
1) POKE命令插入法	(48)
2) DEBUG “插入”	(48)
4.3 彩色作图, 乐曲程序	(51)

1) Circle语句程序例.....	(51)
Circle语句彩色作图例 (娃头)	(52)
Color语句全局测试文本	(53)
2) 彩色作图, 动画音乐程序.....	(54)
运行结果.....	(58)
4.4 RS232接口应用—SR6602绘图驱动.....	(58)
4.5 BASIC语言写的“库存” (INVEN.BAS) 小数据库文件	(59)
4.6 PC班87年春BASIC上机例题选	(62)
五、CP/M86.....	(70)
5.1 HELP提示利用—ED命令	(70)
5.2 ED建立文本例FEP.A86	(73)
5.3 ASM86汇编程序例	(74)
5.4 编译BASIC	(76)
1) ED插入BASIC文本	(76)
2) SBASIC.....	(77)
3) BASGEN	(78)
4) LINK86.....	(78)
六、dBASE II 与CdBASE III	(79)
6.1 dBASE II	(79)
1) 建库与输入数据.....	(80)
2) APPEND FROM, REPORT FORM.....	(81)
6.2 CdBASE II	(82)
1) 建库.....	(82)
2) 报表格式.....	(83)
报表格式EDLIN修改	(83)
3) 命令文件用modi comm建立	(85)
建立.....	(86)
运行.....	(86)
6.3 dBASE 命令文件循环嵌套的例题	(86)
七、微机应用班上机实习纲要	(88)
7.1 BASIC部分.....	(88)
7.2 FORTRAN部分.....	(93)
7.3 C-dBASE部分	(101)
7.4 MSDOS操作系统	(107)
7.5 汇编程序	(115)
附录	(120)
附录A 西文dBASE III 1.0部分提示.....	(120)
文件盘目录.....	(120)
启动菜单.....	(121)

HELP键说明.....	(123)
调。DBF文件看记录.....	(125)
功能键表.....	(126)
dFORMAT命令说明	(126)
附录B PC/XT宏汇编编译差错信息	(129)
附录C PC/XT/AT DOS 3.0系统工具使用说明.....	(134)
1. Symdeb——调试工具	(134)
2. PE ——屏幕编辑	(145)
参考资料	(147)

一、硬件系统

硬件课程课堂讲解后，若时间允许可适当安排些部件设置实习较好，这里将PCTest软盘与异步信口Asynchronous communication Ver 2.00使用，与打印机字型设定作为三例介绍为下：

1.1 PCTEST测试盘使用：此盘有目录如下所示

```
A> dir /w
COMMAND COM PCTEST COM CPU EXE VIDEO EXE MEDIUM DAT HIGH DAT PRI-
NTER EXE MUSIC EXE BASA EXE TEST BAS
SCI EXE KEYBOARD EXE BASICA EXE CHKDSK COM DISKCOPY COM AUTOEXEC BAT
16 File (s)
```

插盘在A驱动器，开机批命令自启动引出如图所示功能任选菜单。

```
A> pctset
PC COMPATIBILITY TESTS, VER 1.20
Enter Letter of Drive containing PCTEST program?
COLUMBIA DATA PRODUCTS presents.....
```

PERSONAL COMPUTER COMPATIBILITY TEST

兼容性测试菜单

- | | |
|------------------------------|--------------|
| 1 RUN ALL TESTS | 1. 全程测试 |
| 2 PROCESSOR TEST | 2. CPU测试 |
| 3 VIDEO TEST | 3. 显示器测试 |
| 4 KEYBOARD TEST | 4. 键盘测试 |
| 5 PRINTER TEST | 5. 打印机测试 |
| 6 MUSIC TEST | 6. 乐曲测试 |
| 7 BASIC LANGUAGE TEST | 7. BASIC语言测试 |
| 8 PLAY"SPACE COMMANDERS"GAME | 8. 打飞碟游戏 |
- Enter Selection (1—8) 任选 (1—8)

PROCESSOR TEST

菜单选2 CPU测试

Press any key to begin test. PROCESSOR EXECUTION SPEED TEST,
The number below should count at a one-second rate.
Press [Esc] key at any time to reset time to 00:00

PRESS ANY OTHER KEY TO CONTINUE TO NEXT TEST.

00:xx

EQUIPMENT REPORT (INTERRUPT 11) :

The following equipment is reported to be present:

1 Parallel Printer

Game Adapter is not installed

1 RS-232 Serial Device

2 Diskette Drives

Video is 80 column color graphics INT 11H 设备检查报告

打(1—8) 可任选一种测试内容。若打1就连续从上图功能2—7进行各部件测试，这些测试都用汇编可执行程序进行，CPU测试可显示处理机时钟走动，其他项测试要打入任意键继续。功能3 video 测试CRT页面显示。功能4 键盘测试。功能6 MUSIC 测试，用汇编程序试几种乐曲，如下图任选菜单。这些乐曲与DOS 2.0 SAMPLE.BAS不同。功能7进入BASIC测试。先显示一页英文人机对话说明，然后返回DOS，你必须调用BASIC EXE

例：A> BASIC A TEST 才能进入BASIC测试。

系统测试中还有INT11部件检查，内存容量 (INT 12) 报告，测得系统实际内存容量值。

VIDEO TEST

菜单选3 CRT测试

Press any key to begin test

KEYBOARD TEST

菜单选4 键盘测试

Press any key to begin test.

PRINTER TEST

菜单选5 打印机测试

Press any key to begin test.

MUSIC TEST

菜单选6 音调测试

Press any key to begin test. MUSIC TEST.

Select one of the following:

- 1-"C" Scales
- 2-On Top of Old Smoky-Traditional
- 3-William Tell Overture-Rossini
- 4-Beautiful Dreamer-Foster
- 5-Theme from "Star Trek"-Courage
- 6-Kum Ba Ya-Traditional

? 1 乐曲测试任选1—6

BASIC LANG. TEST

菜单选7 BASIC语句测试

Press any key to begin test."BASIC LANGUAGE INTERPRETER TEST".
A major requirement for compatibility is the BASIC and ADVANCED:
BA BASICSIC

Language interpreters. The BASIC Language is an important aspect of
the
computer for the following reasons:

- (1) Approximately one-third of all application programs require
BASIC or BASICA in order to run.
- (2) These BASIC interpreters provide access to nearly all features
of the computer. The Graphics, Sound, Disk File and Input/Output
Device Control are features not found in some other BASIC'S.
- (3) BASIC is the most commonly-used Personal Computer Language.
It is easy to learn and well documented for first-time computer
programmers. This allows the user to write custom applications
and (in some cases) to modify purchased application programs for
specific requirements.

PRESS ANY KEY TO CONTINUE...

* * * * IMPORTANT * * * *

If the BASIC interpreter is not provided on the computer's
operating system (DOS) disk (which was booted at the beginning of
these tests), then insert a disk containing the BASIC interpreter in
the boot drive at this time.

WHAT DRIVE CONTAINS THE BASIC INTERPRETER?

Enter letter A, B, C, ... or x if there is no BASIC>>> a
TO TEST BASIC, ENTER A COMMAND EXACTLY AS SHOWN BELOW,
THEN PRESS ENTER KEY;

A:BASICA A:TEST 虽然机器提示如此

A> 只打BASICA TEST能进入BASIC测试态

进入BASICA测试，功能键检查，屏幕显示如图所示CRT底部屏幕功能键内容不断变化。

屏幕进入BASICA测试

FUNCTION KEY statements

(1) DEY ON/KEY OFF: The function key display at the bottom of the screen should blink several times.

(2) Defind KEY: ALL function keys should now be defined as' ABC-DEF'.

(3) ALL function keys should return to their original definition one at a time.

REPEAT this test or CONTINUE <enter R or C> ? 打C往下走
BASIC 乐曲语句试验：

在屏幕显示Do Re Mi等8字符的同时，可听到乐曲声。

1LIST 2RUN 3LOAD" 4SAVE" 5CONT 6, "LPT: 7TRON 8TROFF 9KEY 0SCREEN
SOUND and PLAY statements

(1) SOUND: This should be a sliding note lasting approximately one second.

(2) PLAY FOREGROUND: Each note should play when its name is printed.

Do Re Mi Fa So La Ti Do

(3) PLAY BACKGROUND: Each note should play at a slow tempo, but all notes will be printed as a group when the first note is playing.

Do Re Mi Fa So La Ti Do

曲调伴奏

REPEAT this test or CONTINUE <enter R or c> ?

彩色作图语句试验可看见CRT幕面显示。

COLOR GRAPHICS

(1) CIRCLE: A circle should appear.

; 画圆

(2) LINE: An equator is now drawn.

; 划线

(3) PAINT: The top half is now painted

; 填色

magenta.

(4) DRAW: A cyan

; 画棱形

diamond is now
drawn in the
bottom half.

REPEAT OR CONTINUE <enter R or C> ?

BASIC检查中亦有内存检查报告及ROM检查报告如下所示

The above configuration was reported by the computer's INT 11 function.

It must correctly describe the actual devices present.

PRESS ANY KEY TO CONTINUE...

MEMORY SIZE REPORT (INTERRUPT 12):

The computer's INT 12 function reports memory size is >>> 512K bytes <<<

This test program has measured memory size to be >>> 512K bytes <<
If the above numbers are different, verify that the memory size switches in the computer (if any) are properly set for the amount of memory present

If the switches are incorrectly set, correct them and rerun this test.

PRESS ANY KEY TO CONTINUE...

READ ONLY MEMORY (ROM) CONFIGURATION:

To achieve a high degree of compatibility, the computer should contain a ROM-based BIOS program, which interfaces the system to the keyboard, video display diskette drives, printer, and serial I/O ports.
It should exist from FE000 (or lower) to FFFFF.

This computer contains ROM at the following locations:

from C8000 to C8FFF

from F6000 to FFFFF

PRESS ANY KEY TO CONTINUE...

TIME OF DAY CLOCK (INTERRUPR) 1A) :

The number, below should display minutes and seconds, beginning with 00:00

Press (Esc) key at any time to reset time to 00:00

PRESS ANY OTHER KEY TO END TEST.

到此BASIC测试完毕退回DOS，可选SC1游戏。（功能8：打飞碟游戏）

1.2 硬件系统：RS232联机通迅实习。采用IBM异步通迅软件Ver2.00启动后如下所示：

autoexec

B> date

Current date is the 1-01-1980

Enter new data:

B> time

Current time is 0:01:04.64
Enter new time:
B> rs232int
B> basic terminal/c:o/f:2
IBM Personal Computer
Asynchronous Communications Support
Version 2.00 (C) Copyright IBM Corp.
1981, 1982
Implemented by

The IBM Cambridge Scientific Center
Enter screen width (40 or 80) 80

插此盘在驱动器A：批命令自动引入异步通讯状态。打80回车等待片刻即自显示；终端方式选择菜单如图所示。

Terminal Selection Menu

Choose:

- 1 Dow Jones Service THE SOURCE
- 2 VM/370 Terminal
- 3 TSO Terminal
- 4 User Specified Terminal
- 5 Personal Computer Communications
- 6 Other Terminal Specification File
- 7 Disconnect Communications Line
- 8 Exit Program

Type number and press Enter 5 (PC通信方式)

在图上菜单中选功能5—PC通信——文件传送，资源共享。在功能5之后出现另一菜单如下在此菜单上选2，设定发方和问要送文件名打要送文件名。

Function Selection Menu

Choose:

- 1 Send File Data to Host
- 2 Transmit a Personal Computer File
- 3 Receive a Personal Computer File
- 4 Return to Terminal Operation
- 5 Return to BASIC
- 6 Return to Terminal Selection Menu

进入PC通信后打F2键出现此功能选用菜单，若要发文件，在此要设定一方收，另一方发。

Type number and press Enter (打2发，打3收)

在设定收或发方之后屏幕进入终端状态就可看见文件收发过程。

No characters entered

```

Enter name of local file to be sent to host
cirl.bas ; 打入要发的文件名cirl.bas
Wait for return character from host after each line sent (Y or N) ?
n

Starting file transmission ; ASC II字符文件开始发送内容显示
10 SCREEN 0:SCREEN 1
20 K = 150:KI = 0
30 KK = 0:K Y = 1
40 FOR I = 1 TO 16 STEP 1
50 IF I < 10 THEN II = I * 0.8 ELSE II = I
60 KI = 4 + KI:K = K - I
70 CIRCLE (160, 100 - KI), K, I,, 6.28,.3
80 CIRCLE (160, 100 + KI), K, I,, 6.28,.3
90 CIRCLE (160, 100 - KI), K - 3, 2,, 6.28,.3
100 CIRCLE (160, 100 + KI), K - 3, 1,, 6.28,.3
110 IF KK = 0 THEN KK = 1 ELSE KK = 0
120 NEXT
130 PRINT CHR$ (27), "W"
140 END

File sending complete ; 发送完毕标志
Press Enter to return to terminal operation
Enter name of local file where received file is to be saved
ascii.bas ; 在收方要打接收文件名
Ready to receive file
Ready to send ASCII.BAS
Starting file transmission
Transmission completed ; 文件接收者CRT
Press Enter to return to terminal operation ; 右下角有接收标志 接收
↓
RC 6

Enter name of local file to be sent
ascii.bas ; 文件发送在4.终端方式
Ready to send ASCII.BAS ; 亦可实现 发送
Ready to receive file ; 发方屏幕右下 ↓
Starting file transmission ; 角有发送标志 SN 6
Transmission completed
Press Enter to return to terminal operation
在功能4中联机对话——电子邮件式，亦可作文件传送。
下面是二台PC机用RS232电缆联机后，双方CRT，同样显示任一方键入信息。选择

```

功能4，终端对话方式，双方任一方键入字符，对方同样显示超小网络式“电子邮件”作用有F7打印功能键与F8记盘功能键

You are back as a terminal

Welcome, this is a demostration of computers talking with each other two of KH-16 computer systems connected with rs232 cable, they talk and talk just like good fiends do.

the contents of their talking may be copied down by the FX-100 printer with this an electronic mail completed, other word this machine may be used in any office as automatic tool

Would you try on key to talk with any one?

屏幕右下方功能键三个，按F7打印屏幕内容 按F8将对方信息取文件名记盘 F10提示键

F7 PRINT F8 FILEWRITE F10<HELP

A> print dir232.txt

Name of list device [prn] :prn

Resident part of PRINT installed

Volume in drive A has no label

Directory of A:o

COMMAND	COM ANSI	SYS	FORMAT	COM CHDKSK	COM SYS	COM
DISKCOPY	COM DISKCOMP	COM COMP	COM EDLIN	COM MODE	COM	
FDISK	COM BACKUP	COM RESTORE	COM PRINT	COM RECOUER	COM	
ASSIGN	COM DIR232	TXT GRAPHICS	COM SORT	EXE FINK	EXE	
MORE	COM BASIC	COM BASICA	COM EXE2BIN	EXE LINK	EXE	
DEBUG	COM ARI	BAS SAMPLES	BAS MORTGAGE	BAS COLORBAR	BAS	
MUSIC	BAS DONKEY	BAS CIRCLE	BAS PIECHART	BAS SPACE	BAS	
BALL	BAS COMM	BAS MYFILE	BAT RS	COM TIMER	COM	
DR	COM SD	COM DISKTEST	COM DR	UOL SUPRT	EXE	

60 File (s) 7168 bytes free

异步通信盘应用：

1. 联机对话

2. 文件传送两种功能起了小网络：电子邮件与资源共享作用。
在PC机向一方要调看另一方文件目录的方法比较容易实现：利用DOS命令

A>DIR/W>DIR232.TXT能自动将显示目录建立目录文件
DIR232.TXT。

选用功能4或5，可以将目录文件内容发送给对方。

利用上述命令形成的目录文件，打印结果。其形成过程见如下所示

A> DIR/W> DIR232.TXT

A> DIR/W

Volume in drive A has no label /

Directory of A:>

COMMAND	COM	TERMINAL	BAS	TERMINIT	BAS	UMMOD	TER	TSOMOD	TER
PCMOD	TER	DOWMOD	TER	BASIS	COM	RS232INT	EXE	UPDATE11	BAT
AUTOEXEC	BAT	UPDATE10	BAT	MESSAGE		AAA	LIB	RS232	EXE
CREAT	BAS	RND	BAS	ASCII	BAS	JAZZ	BAS	CIR1	BAS
SNM	BAS	GET	BAS	QQQ	BAS	BASICA	COM	HANCHH	BAS
SUBRT	BIN	SUBRT	BAS	SUBRT	EXE	DIR232	BAT	MODE	COM
PC	TER	DDD	BAS	ASDF		DIR232	TXT	DIR232	

35 File (s) 201728 bytes free

A> type dir232.txt

Volume in drive A has no label

Directory of A:>

COMMAND	COM	TERMINAL	BAS	TERMINIT	BAS	UMMOD	TER	TTOMOD	TER
PCMOD	TER	DOWMOD	TER	BASIC	COM	RS232INT	EXE	UPDATE11	BAT
AUTOEXEC	BAT	UPDATE10	BAT	MESSAGE		AAA	BBB	RS232	EXE
CREAT	BAS	RND	BAS	ASCII	BAS	JAZZ	BAS	CIR1	BAS
SNW	BAS	GET	BAS	QQQ	BAS	BASICA	COM	HANCHB	BAS
SUBRT	BIN	SUBRT	BAS	SUBRT		DIR232	BAT	MODE	COM
PA	TER	DDD	BAS	ASDF	EXE	DIR232	TXT	DIR232	

35 File (s) 201728 bytes free

1.3 打印机字型设定

例举如下例BASIC字型设定LPRINT语句。系统引入CCDOS2.1用FX-100 9针打印机。运行下例程序之后可看到打印机运行结果与说明。较容易选定那种字型该选用哪条语句。

CCDOS 2.1配FX-100 9针打印机

10 WIDTH" LPT1:", 80

15 LPRINT

20 LPRINT CHR\$ (27) +CHR\$ (73) +CHR\$ (65); "汉";

30 LPRINT CHR\$ (27) +CHR\$ (73) +CHR\$ (36); "字";

40 LPRINT CHR\$ (27) +CHR\$ (73) +CHR\$ (67); "系";

50 LPRINT CHR\$ (27) +CHR\$ (73) +CHR\$ (68); "统"; —D 为
最大型字

```

55 LPRINT
60 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (73); "汉"; ——此行语
句最小 (字型 I)
62 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (74); "字";
64 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (75); "系";
66 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (76); "统";
68 LPRINT
70 LPRINT CHR$ (14); "ibm comupter";
80 LPRINT CHR$ (15); "ibm computer";
85 IPRINT
90 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (69); "汉";
92 LPRINT CHR$ (21) +CHR$ (73) +CHR$ (70); "字";
93 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (71); "系";
94 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (72); "统";
100 LPRINT CHR$ (10) +CHR$ (13)
105 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (73);
110 LLIST
120 END

```

〈汉字系统〉字型略

20行~50行打出字型
(Esc + I + D最大)

60~66行打出字型
(Esc + I + I最小)

ibm computer * ibm computer

90~94行打出字型，各转90度

例：要最小汉字必须用第60行语句ESC + I + I但是对各种不同型号的打字机，会有不同的结果，这一点必须实际测试。

在下例题中看出20—60行设控制码以汉字型式对英文字符不作用。“SO”放宽—(70行)，“SI”紧缩—(80行)，“ESC + E”加粗——90行的执行结果在打印纸上显然易见。

ibm computer	imb computer	ibm computer
ibm computer	ibm computer	ibm computer
ibm computer	ibm computer	ibm computer

```

10 WIDTH"1pt1:", 80
20 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (65); "ibm computer";
30 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (66); "ibm computer";
40 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (67); "ibm computer";
50 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (68); "ibm computer";
60 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (69); "ibm computer";
70 LPRINT CHR$ (14); "ibm computer";

```

```
80 LPRINT CHR$ (15) ; ibm computer",
90 LPRINT CHR$ (27) +CHR$ (69) ; "ibm computer",
100 LPRINT CHR$ (10) +CHR$ (13)
110 LLIST
120 END
```

李白诗是汉字输入练习样板，若能在15—30分钟内打出此诗者，初步掌握汉字输入法采用CCDOS 2.1配FX-100打印选J型字结果。

李白诗

床	前	明	月	光
疑	是	地	上	霜
举	头	望	明	月
低	头	思	故	乡

用BASIC语句紧缩〔经过LPRINT CHR\$ (27); "II"〕或CCDOS 2.0/2.1 CTRL+F10选I字型都能选较小字型。」

```
A> 9P
LBS
```

李白诗

床	前	明	月	光
疑	是	地	上	霜
举	头	望	明	月
低	头	思	故	乡

用CCDOS2.0 (CCBIOS) 配FX-100打印机经过ALL9P程序设定。有较大 A-P16 种字型用KH9P设定，有最小字型。所以说汉字打印字型有许多因素，CCDOS版本，打印机型号，及其设定程序都有明显关系。

FX-100打印机内部DIP开关还能设定西文紧缩字型。

M2024或M1724打印机

```
A> type b:LBS
```

BROTHE16命令J型字

李白诗

床	前	明	月	光
疑	是	地	上	霜
举	头	望	明	月
低	头	思	故	乡

FONT.BAS 16字型设定文本

```
10 REM CHINESE FONT TEST
20 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (67) ; "BROTHE16 十六字
型"
30 FOR I=0 TO 15
40 A=65+I
50 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (A) ; CHR$ (A) ; "型：";
60 PRINT"汉字系统"
70 LPRINT"汉字系统"；"THE INSTITUTE OF COMPUTING TECHNO-
LOGY"
80 LPR INT:LPRINT
90 NEXT I
100 LPRINT CHR$ (27) +CHR$ (73) +CHR$ (67)
110 END
```

运行此程序循环显示CCDOS 2.0/2.1 A-P 16种字型
〈汉字系统〉字型略

二、PC DOS 2.00系统

2.1 EDLIN—文本建立

PC DOS系统EDLIN命令可以建立多种源程序文本。亦可将老文本调来作增删修改。

```
A> edlin autoexec.bat
End of input file
* L
 1: * dir/w
 2: * type dr.doc
 3: * basica music
* 3d
* L
 1:dir/w
 2:type dr.doc
* 2
 2:* type dr.doc
 2:* copy dr.doc
* L
 1: dir/w
 2:* copy dr.doc
```

EDLIN命令

修改autoexec.bat文本

L命令调入

取消第三行

修改第二行

改后LIST查看

*31	加插第三行
3: * @	打-F5功能键退出插入态，样版行改当前行 仍可打入要改内容
dir/w b:	
4: * type dr, doc	
5: * ^C	CTRL-Break退出插入
* L	态再LIST查看
1: * dir/w	
2: * copy dr.doc	
3: * dir/w b:	
4: * type dr.doc	
* 2	修改第二行
2: * copy dr.doc	
3: * copy dr.doc b:	
* e	改后e命令存盘退回DOS
A> TYPE AUTOEXEC.BAT	
DIR/W	在DOS用TYPE命令看改过的文本
COPY DR.DOC B:	
dir/w b:	
type dr.doc	

上面所示将老文本调入内存作增删修改，改完用E命令存盘回DOS后，TYPE命令打印显示。

运用EDLIN命令增删修改文本时，有用的特殊编辑键，一般书上说得与机器键盘刻字不一致的地方括要如下：

功 能	键 盘 键 名	说 明
<COPY1>	F1	打一次COPY一个字符
<COPYUP>	F2	打F2后要指定COPY终止字符
<COPYALL>	F3	打一次全部复制
<SKIPI>	DEL	删去一个字符
<SKIPUP>	F4	打F4后要指定COPY起始字符
<VOID>	<esc>	取消当前输入
<Insert>	INS	进入/退出插入方式
<Replace>	F6	退出插入或字符终止。（见r命令用例）
<Newline>	F5	使当前行成为样板行。 或脱出命令态仍可接受编辑命令。

2.2 Autoexec.BAT批命令执行过程

```
A> dir/w
Volume in drive A has no label
Directory of A:\
```