



National Fire Codes[®] 1985

National Fire Codes[®]

A Compilation of NFPA Codes, Standards,
Recommended Practices, Manuals and Guides

Volume 6



江苏工业学院图书馆
藏书章

This is one of 8 volumes of the *National Fire Codes* published by the National Fire Protection Association. The complete set contains the codes, standards, recommended practices, manuals and guides developed by the technical committees of the Association and processed in accordance with the NFPA Regulations Governing Committee Projects.

National Fire Protection Association
Batterymarch Park, Quincy, MA 02269

NATIONAL FIRE PROTECTION ASSOCIATION

Batterymarch Park, Quincy, MA 02269

The National Fire Protection Association was organized in 1896 to promote the science and improve the methods of fire protection and prevention, to obtain and circulate information on these subjects and to secure the cooperation of its members in establishing proper safeguards against loss of life and property by fire. The Association is an international, charitable, technical and educational organization. Its membership includes over one hundred and fifty national and regional societies and associations and over thirty-two thousand individuals, corporations, and organizations. Anyone interested may become a member; membership information is available on request.

Library of Congress Catalog Card No. 38-27236

Volume 6 — ISBN: 0-87765-009-8

Complete Set — ISBN: 0-87765-140-X

ISSN: 0077-4545

Copyright © 1985

National Fire Protection Association

All Rights Reserved

Licensing Provision

This document is copyrighted by the National Fire Protection Association (NFPA). Public authorities and others are urged to reference this document in laws, ordinances, regulations and administrative orders or similar instruments. Any deletions, additions and changes desired by the adopting authority must be noted separately. Those using this method ("adoption by reference") are requested to notify the NFPA (attention: Secretary, Standards Council) in writing of such use.

The term "adoption by reference" means the citing of the title and publishing information only. For permission to print and to publish any individual document contained in this publication, see the copyright statement in the pamphlet edition of that document or contact NFPA.

(For further explanation, see the Policy Concerning Adoption, Printing and Publication of NFPA Documents which is available upon request from the NFPA.)

Printed in U.S.A.

Published in Quincy, Massachusetts

National Fire Codes

The *National Fire Codes* are annual compilations of the Codes, Standards, Recommended Practices, Manuals, Guides and Model Laws prepared by Technical Committees organized under NFPA sponsorship in accordance with the published procedures of the Association. Only those documents which have been adopted by the Association are included in the *National Fire Codes*.

The Board of Directors of the Association appoints persons from those vitally interested, qualified, and active in the areas with which the Committees are concerned so as to achieve a fair balance of affected interests. All service on these NFPA Technical Committees is contributed voluntarily in support of the Association's program for firesafety. While these procedures assure the highest degree of care, neither the National Fire Protection Association, its members, nor those participating in its activities accept any liability resulting from compliance with the provisions given herein, for any restrictions imposed on materials or processes, or for the completeness of the text. Users should realize that complete reliance for firesafety can never rest exclusively on any single safeguard.

The committees responsible for the various texts published herein are given in the introductory sections preceding each. Current committee lists are published in the *NFPA Yearbook*, which may be obtained from the Association. Official records of the adoption of each standard will be found in the *NFPA Technical Committee Reports*, the *Technical Committee Documentation* and *Fire Journal*, a bimonthly membership publication of the Association.

Volumes 1 through 6 contain documents which have been judged suitable for legal adoption and enforcement (Codes and Standards).

Volumes 7 and 8 contain Recommended Practices, Manuals and Guides which are generally referred to as good engineering practices. Also included in these volumes are such documents as model laws and enabling acts which will be found to be particularly helpful to enforcing agencies.

Many of the documents have been approved by the American National Standards Institute as American National Standards. Most of the documents contained in these volumes are also published by the Association in separate pamphlet form.

Users of this document should consult applicable Federal, State and local laws and regulations. NFPA does not, by the publication of this document, intend to urge action which is not in compliance with applicable laws and this document may not be construed as doing so.

Policy adopted by NFPA Board of Directors on December 3, 1982

The Board of Directors reaffirms that the National Fire Protection Association recognizes that the toxicity of the products of combustion is an important factor in the loss of life from fire. NFPA has dealt with that subject in its technical committee documents for many years.

There is a concern that the growing use of synthetic materials may produce more or additional toxic products of combustion in a fire environment. The Board has, therefore, asked all NFPA technical committees to review the documents for which they are responsible to be sure that the documents respond to this current concern. To assist the committees in meeting this request, the Board has appointed an advisory committee to provide specific guidance to the technical committees on questions relating to assessing the hazards of the products of combustion.

Official NFPA Definitions

Extracted from the *Regulations Governing Committee Projects*

Section 2. Terms and Definitions.

2-2 Definitions. Where the following terms, commonly found in the Association Committee Documents, are used or defined in the body of the text of a Standard, Code, Recommended Practice, Manual or Guide, they shall be consistent with the intent of these meanings, but these "definitions" may be altered by a Committee to fit the individual needs of the Document. Such altered definition shall be clear and unambiguous in the context in which it is used.

Approved: means "acceptable to the authority having jurisdiction."

NOTE: The National Fire Protection Association does not approve, inspect or certify any installations, procedures, equipment or materials; nor does it approve or evaluate testing laboratories. In determining the acceptability of installations or procedures, equipment or materials, the authority having jurisdiction may base acceptance on compliance with NFPA or other appropriate standards. In the absence of such standards, said authority may require evidence of proper installation, procedure or use. The authority having jurisdiction may also refer to the listings or labeling practices of an organization concerned with product evaluations which is in a position to determine compliance with appropriate standards for the current production of listed items.

Authority Having Jurisdiction: The "authority having jurisdiction" is the organization, office, or individual responsible for "approving" equipment, an installation, or a procedure.

NOTE: The phrase "authority having jurisdiction" is used in NFPA Documents in a broad manner since jurisdictions and "approval" agencies vary as do their responsibilities. Where public safety is primary, the "authority having jurisdiction" may be a federal, state, local, or other regional department or individual such as a fire chief, fire marshal, chief of a fire prevention bureau, labor department, health department, building official, electrical inspector, or others having statutory authority. For insurance purposes, an insurance inspection department rating bureau, or other insurance company representative may be the "authority having jurisdiction." In many circumstances, the property owner or his designated agent assumes the role of the "authority having jurisdiction"; at government installations, the commanding officer or departmental official may be the "authority having jurisdiction."

Code: A Document containing only mandatory provisions using the word "shall" to indicate requirements and in a form generally suitable for adoption into law. Ex-

planatory material may be included only in the form of "fine print" notes, in footnotes, or in an appendix.

Labeled: Equipment or materials to which has been attached a label, symbol, or other identifying mark of an organization acceptable to the authority having jurisdiction and concerned with product evaluation, that maintains periodic inspection of production of labeled equipment or materials and by whose labeling the manufacturer indicates compliance with appropriate standards or performance in a specified manner.

Listed: Equipment or materials included in a list published by an organization acceptable to the authority having jurisdiction and concerned with product evaluation, that maintains periodic inspection of production of listed equipment or materials and whose listing states either that the equipment or material meets appropriate standards or has been tested and found suitable for use in a specified manner.

NOTE: The means for identifying listed equipment may vary for each organization concerned with product evaluation, some of which do not recognize equipment as listed unless it is also labeled. The authority having jurisdiction should utilize the system employed by the listing organization to identify a listed product.

Manual or Guide: A Document which is informative in nature and does not contain requirements.

Recommended Practice: A Document containing only advisory provisions (using the word "should" to indicate recommendations) in the body of the text.

Shall: Indicates a mandatory requirement.

Should: Indicates a recommendation or that which is advised but not required.

Standard: A Document containing only mandatory provisions using the word "shall" to indicate requirements. Explanatory material may be included only in the form of "fine print" notes, in footnotes, or in an appendix.

Notes and footnotes are informative only and are not mandatory.

NOTICE

All questions or other communications relating to documents in this volume should be sent only to NFPA Headquarters, addressed to the attention of the Committee responsible for the document.

For information on obtaining Formal Interpretations of the documents, proposing Tentative Interim Amendments, proposing amendments for Committee consideration, and on matters relating to the content of the document, write to the Secretary, Standards Council, National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

A statement, written or oral, that is not processed in accordance with Section 16 of the Regulations Governing Committee Projects shall not be considered the official position of NFPA or any of its Committees and shall not be considered to be, nor be relied upon as, a Formal Interpretation.

VOLUME 6

Table of Contents

<i>Titles</i>	<i>Pages</i>
Flame-Resistant Textiles and Films, Standard Methods of Fire Tests for	701 1
Flammability of Wearing Apparel, Classification of	702 1
Building Materials, Fire Retardant Treatments of	703 1
Fire Hazards of Materials, Identification of	704 1
Nuclear Power Plants, Fire Protection for	803 1
Fire Fighter Professional Qualifications	1001 1
Fire Apparatus Driver/Operator Professional Qualifications	1002 1
Airport Fire Fighter Professional Qualifications	1003 1
Fire Fighter Medical Technicians Professional Qualifications	1004 1
Fire Officer Professional Qualifications	1021 1
Professional Qualifications for Fire Inspector, Fire Investigator and Fire Prevention Education Officer	1031 1
Fire Service Instructor Professional Qualifications	1041 1
Code for Unmanned Rockets	1122 1
Public Display of Fireworks	1123 1
Fireworks, Manufacture, Transportation, and Storage of	1124 1
Planned Building Groups, Fire Protection in	1141 1
Public Fire Service Communications, Installation, Maintenance and Use of	1221 1
Water Supplies for Suburban and Rural Fire Fighting	1231 1
Initial Fire Attack, Training Standard on	1410 1
Fire Department Safety Officer	1501 1
Automotive Fire Apparatus	1901 1
Testing Fire Department Aerial Ladders and Elevating Platforms	1904 1
Fire Department Portable Pumping Units	1921 1
Fire Department Ground Ladders	1931 1
Fire Department Ground Ladders, Use, Maintenance, and Service Testing of	1932 1
Fire Hose	1961 1
Care, Use, and Maintenance of Fire Hose Including Connections and Nozzles	1962 1
Fire Hose Connections, Screw Threads and Gaskets for	1963 1
Protective Clothing for Structural Fire Fighting	1971 1
Structural Fire Fighters' Helmets	1972 1
Gloves for Structural Fire Fighters	1973 1
Self-Contained Breathing Apparatus for Fire Fighters	1981 1
Personal Alert Safety Systems (PASS) for Fire Fighters	1982 1

© 1977 NFPA, All Rights Reserved

Standard Methods of Fire Tests for Flame-Resistant Textiles and Films

NFPA 701-1977

1977 Edition of NFPA 701

This 1977 edition supersedes the 1976 edition of the Standard and differs from that edition due to the amendments which were adopted by the National Fire Protection Association at its Fall Meeting on November 15, 1977.

Origin and Development of NFPA 701

Requirements for flameproofing of textiles were adopted by the NFPA on recommendation of the Committee on Fireproofing and Preservative Treatments in 1938. These were amended in 1939, 1940, 1941 and 1951. This standard is now under the jurisdiction of the NFPA Committee on Fire Tests; the 1966 edition, which was an extensive revision of the previous edition, was prepared by that committee as were the 1968, 1969, 1975, 1976 and 1977 editions.

Committee on Fire Tests

Jack Bono, *Chairman*

Underwriters Laboratories Inc., 1285 Walt Whitman Road
Melville, Long Island, NY 11746

M.S. Abrams, Portland Cement Association

Irwin A. Benjamin, National Bureau of Standards

James R. Bercaw, Man Made Fiber Producers Association

John A. Blair, Society of the Plastics Industry

Herbert B. Carlsen, Gypsum Association

Robert W. Dougherty, M & M Protection Consultants

Buell B. Dutton, Building Officials and Code Administrators, International

Richard G. Gewain, American Iron and Steel Institute

George B. Krumholz, Jr., U.S. Testing Company

Gerald E. Lingenfelter, American Insurance Association

W.F. Maroni, Factory Mutual Research Corporation

William H. McLain, Southwest Research Institute

E.E. Miller, Industrial Risk Insurers

Norman S. Pearce, Underwriters' Laboratories of Canada

T.P. Pritsker, The Dallas Laboratories

Dr. A.F. Robertson, National Bureau of Standards

John Ed Ryan, National Forest Products Association

Louis Segal, Fire Marshals Association of North America

Herman Spaeth, Insurance Services Office

K. Sumi, National Research Council of Canada

Lewis W. Vaughn, Canadian Sheet Steel Building Institute

Alternates

J.S. Barritt, Industrial Risk Insurers
(Alternate to E.E. Miller)

David Brackett, Gypsum Association
(Alternate to H.B. Carlsen)

R.B. Buchan, National Forest Products Association
(Alternate to J.E. Ryan)

B.J. Callahan, Factory Mutual Engrng. Corp.
(Alternate to W. F. Maroni)

Peter B. McOrmond, Insurance Services Office
(Alternate to H. Spaeth)

G.M. Watson, American Insurance Association
(Alternate to G.E. Lingenfelter)

Nonvoting

A.J. Bartosic, ASTM D-20 Committee

This list represents the membership at the time the Committee was balloted on the text of this edition. Since that time, changes in the membership may have occurred.

Table of Contents

Introduction	701- 4
0-1 General Considerations	701- 4
0-2 Applications of Flame-Resistant Fabrics	701- 4
0-3 Flame-Resistant Treatments	701- 4
0-4 Physical Properties of Treated Fabrics	701- 4
Chapter 1 General	701- 5
1-1 Scope	701- 5
1-2 Purpose	701- 5
1-3 General Description	701- 5
1-4 Test Selection	701- 5
Chapter 2 Test Apparatus and Materials	701- 5
2-1 Pre-Conditioning Oven	701- 5
2-2 Small-Scale Test Apparatus	701- 5
2-3 Large-Scale Test Apparatus	701- 6
2-4 Test Specimens	701- 6
Chapter 3 Flame Test Procedures	701- 6
3-1 Small-Scale Test	701- 6
3-2 Large-Scale Test	701- 7
Chapter 4 Cleaning and Weathering Procedures	701- 7
4-1 General Considerations	701- 7
4-2 Application	701- 8
4-3 Accelerated Dry Cleaning	701- 8
4-4 Accelerated Laundering	701- 8
4-5 Accelerated Water Leaching	701- 8
4-6 Accelerated Weathering	701- 8
Chapter 5 Flame Resistance Requirements	701- 9
5-1 Small-Scale Test	701- 9
5-2 Large-Scale Test	701- 9
Chapter 6 Field Test: Match Flame Test	701-10
6-1 Test Materials	701-10
6-2 Test Method	701-10
6-3 Test Requirements	701-10
Appendix A	701-10
Appendix B	701-11
Appendix C	701-13
Appendix D	701-14
Appendix E	701-14
Appendix F	701-14

Standard Methods of Fire Tests for Flame-Resistant Textiles and Films

NFPA 701-1977

Introduction

0-1 General Considerations.

0-1.1 While it is not possible to make combustible textiles and films completely resistive to charring and decomposition when exposed to flame or high temperature, a degree of flame resistance can be achieved. Natural fiber textiles can be treated chemically to reduce their flammability and tendency toward smoldering and synthetic fibers and plastic films can be formulated to be flame resistant, the flame-retardant chemicals being incorporated into the resin formulation. Both approaches may be necessary to impart flame resistance to materials in which natural and synthetic fibers are blended. It should be noted, however, that combinations of the non-combustible fibers with a relatively small percentage of combustible fibers will cancel the noncombustible effect.

0-1.2 The hazards introduced by combustible textiles may, of course, be avoided entirely where the use of such noncombustible fibers as glass and asbestos is practical.

0-2 Applications of Flame-Resistant Fabrics.

0-2.1 Standards for theatre scenery, curtains, and furnishings in places of public assembly are commonly set by law.

0-2.2 Flame-resistant fabrics are used in hotels, hospitals, and similar occupancies in the interest of the preservation of lives and property from fire.

0-2.3 Flame-resistant fabrics are also used as work clothing in industries where exposure to heat, open flames, and flash fire is a possibility.

0-2.4 Fabrics treated for flame and weather resistance are used for tents, awnings, tarpaulins, and other outdoor protective covering.

0-2.5 Flame-resistant synthetic materials, in the form of woven fabrics and plastic films, are used decoratively and for protective coverings. Many of these materials will soften and melt when exposed to heat and fire. They may also be subject to twisting, shrinking, dripping, and elongation when subjected to fire conditions.

0-2.6 Reinforced plastic films with flame-resistant qualities are used in air-supported structures.

0-2.7 Transparent plastic films are often used as a temporary enclosure for greenhouses and for construction work.

0-3 Flame-Resistant Treatments.

0-3.1 An increasing range of flame-resistant treatments for natural fiber materials is becoming available. The selection of a particular treatment is governed by the intended use of the treated fabric.

0-3.2 Treatments based on water-soluble chemicals are generally the least expensive and most easily applied, but they are subject to removal by the leaching action of water in laundering, scrubbing, or exposure to weather.

0-3.3 Some treatments may be impaired by the action of the solvents used in dry cleaning and some may gradually lose their effectiveness under conditions of storage and use not involving leaching.

0-3.4 Relatively temporary treatments are suitable only where proper retreatment and renewal can be assured or for decorations and other items which are used briefly, then discarded.

0-3.5 Situations where retreatment is uncertain or not feasible indicate the choice of one of the most durable treatments which are suitable for clothing and decorative fabrics. A number of these will withstand extensive laundering and dry cleaning, although they are higher in cost than the water-soluble type and require professional application.

0-3.6 For outdoor use, treatments have been developed which may be expected to remain effective for the useful life of the fabric under normal conditions of weather exposure.

0-3.7 It should be noted that painting or coating a treated or noncombustible fabric may impair its flame-resistant qualities unless the coating is itself flame-resistant.

0-4 Physical Properties of Treated Fabrics.

0-4.1 A number of factors, which will vary in importance depending on the end use of the fabric, should be considered in selecting a flame-resistant treatment.

0-4.1.1 The effect on the appearance, texture, and flexibility of the fabric is often of primary concern.

0-4.1.2 Some treatments may leave a fabric objectionably stiff, or it may become tacky at high atmosphere temperatures or brittle at low temperatures.

0-4.1.3 Some flame-retardant chemicals are so hygroscopic as to dampen the fabric; others may effloresce to the extent of reduced effectiveness as well as unsightly appearance.

0-4.1.4 Treatment may result in a reduction in strength of the fabric. Also, some flame-retardant chemicals may tend to deteriorate wood or corrode metal with which the treated fabric comes in contact.

0-4.2 In all instances, the possibility of adverse physiological reactions in persons handling or otherwise

exposed to the treated fabric must be considered by the manufacturer.

Standard Methods of Fire Tests for Flame-Resistant Textiles and Films

NFPA 701-1977

Chapter 1 General

1-1 Scope.

1-1.1 These requirements apply to flame-resistant materials which are used extensively in the interior furnishing of buildings and transport facilities, in protective clothing for certain occupations and situations, and for protective outdoor coverings such as tarpaulins and tents. The flame-resistant requirements are not dependent on the type of treatment, except that where durability to laundering or weathering is claimed, the fabric is tested for flame resistance after being subjected to the applicable cleaning or exposure procedures.

1-1.2 These requirements also apply to plastic films, with or without reinforcing or backing, when used for decorative or other purposes inside buildings or as temporary or permanent enclosure for places of public assembly and buildings under construction.

1-1.3 If these materials are to be applied to surfaces of building or backing materials as interior finishes for use in buildings, the test shall be conducted and the material classified in accordance with *Method of Test of Surface Burning Characteristics of Building Materials, NFPA 255*.

1-2 Purpose.

1-2.1 It is the intent of these requirements to provide tests to determine whether the flame-resistant textiles and films are comparatively difficult to ignite and whether it is comparatively difficult to propagate flame beyond the area exposed to the source of ignition.

1-2.2 These performance tests do not necessarily indicate whether the material tested will resist the propagation of flame under severe fire exposure or when used in a manner which differs substantially from test requirements.

1-3 General Description.

1-3.1 Two methods of assessing flame resistance are described. Both methods will provide a comparison among textiles and films but do not necessarily indicate the behavior of a material in a large building fire or other conflagration.

1-3.1.1 The small-scale test employs a relatively small sample and small igniting flame. It is simple and convenient for general use. The small-scale test is commonly used to indicate susceptibility to flame spread from small ignition sources, but may also be used as a screening test prior to large-scale testing.

1-3.1.2 The large-scale test requires a much larger sample and applies a more severe fire exposure which will more nearly approach severe fire conditions. Initial screening may be done with the small-scale test. This method is also useful for investigating the flammability of fabrics when hung in folds.

1-4 Test Selection.

1-4.1 All flame-resistant textiles and films shall be capable of complying with the performance requirements of either the small- or the large-scale tests or both. The authority having jurisdiction shall determine whether both the small- and the large-scale tests are required and this will generally depend on the purpose to be served or the nature of the materials tested.

1-4.2 For those materials which show excessive melting or shrinkage by the small-scale test, then the large-scale test shall be considered applicable.

1-4.3 Textiles which are expected to retain their flame resistance through dry cleaning, laundering, water leaching, or weathering exposures shall be subjected to the applicable procedures of Chapter 4 before being tested by either the small-scale or the large-scale flame test.

Chapter 2 Test Apparatus and Materials

2-1 Pre-Conditioning Oven.

2-1.1 A forced draft oven shall be used to properly condition test specimens prior to testing in either the small-scale test or the large-scale test.

2-1.1.1 The interior of the oven shall be large enough to provide free air flow around each specimen contained.

2-1.1.2 The oven shall have variable temperature control.

2-2 Small-Scale Test Apparatus.

2-2.1 Specimen Holder.

2-2.1.1 A metal holder, having clamps arranged to grip the specimen along its edges only, shall be used to support the specimen. The ends of the specimen shall remain free.

2-2.2 Test Shield.

2-2.2.1 The specimen and its holder shall be supported in the vertical position within a metal shield having a depth of 12 inches, a width of 12 inches and a height of 30 inches.

(a) The shield shall be open at the top and shall be provided with baffled vent openings along the bottom of at least two sides, totaling 6 square inches of free vent area.

(b) The shield shall also have a glass door or panel.

2-2.3 Gas Burner.

2-2.3.1 A Bunsen or Tirrell gas burner, approximately 6 inches high and $\frac{3}{8}$ -inch tube diameter, shall be used as an ignition source.

(a) The burner shall be supported so that its barrel will be at a 25 degree angle with vertical.

(b) The burner shall have means for being moved into test position after the shield has been closed.¹

(c) The gas supply to the burner shall be natural gas or a mixture of natural and manufactured gases having a heat value of approximately 800-1000 BTU per cubic foot.

2-2.4 Hook and Weight.

2-2.4.1 A hook and weight assembly shall be used to determine the length of char or destruction of the specimen.

(a) The combined weight of the assembly shall follow Table 2-2.4

Table 2-2.4
Tearing Weights — Small-Scale Test

Weight of Treated Fabric Being Tested	Total Tearing Weight for Determination of Length of Char
Ounces per Square Yard	Pounds
2 to 6 inclusive	0.25
Over 6 and not exceeding 15	0.5
Over 15 and not exceeding 23	0.75
Over 23	1.00

2-3 Large-Scale Test Apparatus.

2-3.1 Test Enclosure.

2-3.1.1 The test shall be carried out in a sheet-iron stack 12 inches square and 7 feet high.

(a) The stack shall be supported 1 foot above the floor by legs and shall be open at the top and bottom.

(b) The stack shall also be fitted with a wired-glass observation window extending the full length of the front.

(c) The stack shall have means for hanging the specimen.

2-3.2 Restraining Clamps.

2-3.2.1 Test specimens shall be lightly restrained laterally in the stack by suitable clamps and guide wires attached to the outer edges of the specimen.

Exception: Folded specimens may not require clamps.

¹A rod attached to the base of the burner and extending through a slot at the bottom of the shield will serve the purpose.

2-3.3 Gas Burner.

2-3.3.1 A Bunsen burner having $\frac{3}{8}$ -inch tube diameter and means for measuring the gas pressure shall be used for the ignition source.

(a) The burner shall be fixed in a position so that the barrel is at a 25 degree angle with the vertical.

(b) The gas supply to the burner shall be natural gas or a mixture of natural and manufactured gases having a heat value of 800 to 1000 BTU per cubic foot.

(c) The burner tube shall be fully adjustable so as to vary flame height and pattern.

2-4 Test Specimens.

2-4.1 Small-Scale Test.

2-4.1.1 Five specimens of the material, $2\frac{3}{4}$ by 10 inches, shall be cut with their long dimension in the direction of the warp and five in the direction of the filling.

2-4.1.2 Each lot of five shall be cut from at least four places in the sample separated sufficiently to give indication as to the uniformity of the flame-resistant treatment.

2-4.2 Large-Scale Test.

2-4.2.1 The test specimens shall be taken from as widely separated and symmetrically located sections as possible over the entire area of the sample of each fabric. One-half of the specimens of each kind shall be cut with the long dimension in the direction of the warp, and the balance of the specimens shall be cut with the long dimension in the direction of the fill.

2-4.2.2 For conducting flame tests of fabrics in single sheets, at least 10 specimens, 5 inches by 7 feet, shall be used.

2-4.2.3 For conducting flame tests of fabrics hung in folds, at least 4 specimens, 25 inches by 7 feet, shall be cut. Each specimen shall be folded longitudinally to form four folds, each approximately 5 inches wide, uniformly over the length (spacing about $\frac{1}{2}$ inch).

Chapter 3 Flame Test Procedures

3-1 Small-Scale Test.

3-1.1 Preconditioning of Test Specimens.

3-1.1.1 The test specimens shall be conditioned in an oven at temperatures of 140-150 degrees Fahrenheit, for durations of one to one and one-half hours prior to testing.

3-1.1.2 Materials which distort or melt at the above indicated oven exposure are to be conditioned at 60-80 degrees Fahrenheit and 25-50 percent relative humidity for not less than 24 hours.

3-1.1.3 Specimens shall be removed from the ovens one at a time and immediately subjected to the procedures described in Sections 3-1.2 and 3-1.3.

3-1.2 Mounting of Test Specimens.

3-1.2.1 The specimen shall be placed on the specimen holder and clamped so that a strip 2 inches wide and 10 inches long is left exposed.

3-1.2.2 The specimen and its holder shall be supported within the test shield so that its lower end will be $\frac{3}{4}$ inch above the top of the gas burner.

3-1.3 Conducting the Flame Test.

3-1.3.1 The gas burner shall be ignited and, with the air supply completely shut off, shall be adjusted to give a luminous flame about $1\frac{1}{2}$ inches long.

3-1.3.2 The burner shall be moved after the specimen so that the flame is applied vertically to the lower end of the specimen, near the middle of its width. The flame shall be applied for 12 seconds, then withdrawn.

3-1.3.3 The duration of flaming of the specimen shall be noted after withdrawal of the burner.

3-1.4 Measurement of Length of Char or Material Destruction.

3-1.4.1 After all flaming and afterglow on the specimen has ceased, the length of char or material destruction shall be determined immediately. The length of char in this test is defined as the distance from the end of the specimen which was exposed to the flame to the end of a tear made lengthwise of the specimen through the center of the charred area in the following manner:

(a) The specimen shall be folded lengthwise and creased by hand along a line through the highest point in the charred area.

(b) The hook of the hook/weight assembly is inserted in the specimen, on one side of the charred area, $\frac{1}{4}$ inch in from the adjacent outside edge and $\frac{1}{4}$ inch up from the bottom.

(c) The specimen is then grasped on the opposite side of the charred area with the fingers, and raised gently until it supports the weight. The specimen will tear through the charred area until fabric strong enough to carry the load is reached.

3-1.4.2 When it is not feasible to measure char, the material destruction can normally be judged as the measurement from the bottom of the sample to a horizontal line above which all material is sound and in original condition.

3-2 Large-Scale Test.

3-2.1 Preconditioning of Test Specimens.

3-2.1.1 The test specimens shall be conditioned in an oven, at temperatures of 140-145 degrees Fahrenheit for durations of not less than one hour nor more than one and one-half hours before testing.

3-2.1.2 Materials which distort or melt at the above indicated oven exposure shall be conditioned at 60-80 degrees Fahrenheit and 25-50 percent relative humidity for not less than 24 hours.

3-2.1.3 Specimens shall be removed from the oven one at a time and immediately subjected to the procedures described in Sections 3-2.2 and 3-2.3.

3-2.2 Mounting of Test Specimens.

3-2.2.1 The single-sheet specimen shall be suspended vertically in the stack with its full width facing the observer so that the bottom of the specimen will be 4 inches above the top of the Bunsen burner.

3-2.2.2 For the folded specimen the conditions of test shall be the same as above except that it shall be suspended vertically with the edges of the folds facing the observer. The folds shall be spread apart about $\frac{1}{2}$ inch by means of guide rods inserted at the top and bottom ends.

3-2.3 Conducting the Flame Test.

3-2.3.1 The gas burner shall be ignited and the gas pressure regulated at $4\frac{1}{4}$ inches (108 mm) of water.

3-2.3.2 The burner shall be adjusted to produce an 11-inch oxidizing flame having an indistinct inner cone.

3-2.3.3 The flame shall be applied vertically near the middle of the width of the lower end of the specimen in a single sheet, or to the middle of the width of the lower end of the middle fold of the specimen in folds. The position of the specimen relative to the test flame shall be maintained by guide wires attached to the outer edges of the specimen. The test flame shall be applied to the specimen for two minutes, then withdrawn.

3-2.3.4 The duration of flaming combustion on the specimen shall be recorded after withdrawal of the burner.

3-2.4 Measurement of Length of Char.

3-2.4.1 After all flaming and afterflow on the specimen has ceased, the length of char shall be determined. For purposes of this test, the length of char is defined as the vertical distance of the specimen from the top of the test flame to the top of the charred area resulting from spread of flame and afterglow. For synthetic textiles and films the length of char is defined as the vertical distance from the tip of the test flame to a horizontal line, above which all material is sound and in essentially original condition.

Chapter 4 Cleaning and Weathering Procedures

4-1 General Considerations.

4-1.1 The probable durability of a treatment relative to the life of the fabric is difficult to assess but, in general, flame-retardant treatments tend to be either very tenacious or quite easily removed.

4-2 Application.

4-2.1 These procedures shall be applied to fabrics which are expected to retain their flame-resistant qualities through dry cleaning, laundering, weathering, or other exposures to water.

4-2.2 Each fabric shall be subjected to only those exposure procedures which are applicable to its intended use. It shall meet the flame resistance requirements of Chapter 5 after passing through the appropriate exposure cycles.

4-2.2.1 It is believed that such accelerated exposure tests as those described in this section provide sufficient testing to permit a reasonable appraisal of the durability of the treatment (under the conditions for which it was designed) for the useful life of the fabric.

4-3 Accelerated Dry Cleaning.

4-3.1 The treated fabric shall be cleaned in a Coin-op dry cleaning apparatus¹ as part of a 4-lb. (1.82-kg) load made up with dummy pieces of dry cleanable fabrics.

4-3.2 The Coin-op apparatus with perchlorethylene solvent (about 1 percent charge system) shall be run for the full cycle which includes tumble drying. At the end of each dry cleaning cycle, remove the load from the unit and separate the pieces.

4-3.3 The above dry cleaning is repeated until ten complete cycles of cleaning and drying have been realized.

4-3.4 Test specimens shall then be cut from the dry cleaned fabric for testing.

4-4 Accelerated Laundering.

4-4.1 A sample of the treated fabric shall be washed in an automatic commercial washing machine using a solution containing 0.15 percent solution of tallow soap and 0.20 to 0.25 percent alkali.

4-4.2 The operating cycle outlined in Table 4-4 shall be followed.

4-4.3 The sample shall then be dried in a drying tumbler at 250 degrees F.

4-4.4 The above procedure shall be repeated until ten complete cycles of washing and drying have been accomplished.

4-4.4.1 If the material is to be subjected to a special use, more laundering may be required.

4-4.5 Where instructions for laundering a fabric are supplied by the manufacturer or finisher, those instructions

¹ Norge Coin-Op Dry Cleaning Model DML-5832 or equivalent meeting the following criteria:

- Capacity: 10 lbs. (4.5 kg)
- Drum diam: 26 in. (66 cm)
- Drum depth: 16 in. (41 cm)
- Number of fins: 4
- Cleaning cycle rpm: 46
- Spin cycle rpm: 162/325

Table 4-4
Operating Cycle for Accelerated Laundering¹

Operation	Time, Min.	Temp. — Deg. F.
1. Sudsing	6	130
2. Sudsing	6	160
3. Sudsing	6	160
4. Bleaching	8	150
5. Rinsing	2	160
6. Rinsing	2	160
7. Rinsing	2	160
8. Rinsing	2	130
9. Bluing	3	100
10. Scouring	3	100

¹ This cycle is intended for white fabrics. For colored fabrics, the bleaching and bluing operations are omitted and the temperature of the "Sudsing" and "Rinsing" operations is reduced 30 degrees F.

tions should be followed in preference to the above procedure which simulates a typical commercial laundering practice.

4-5 Accelerated Water Leaching.

4-5.1 A sample of the treated fabric shall be totally submerged in a vessel containing tap water at room temperature for a period of 72 hours. The vessel shall have a capacity of at least four gallons of water.

4-5.2 The water shall be drained from the tank and replenished at 24-hour intervals during the immersion period.

4-5.3 At the conclusion of the immersion period, the sample shall be removed from the test vessel and dried at room temperature.

4-6 Accelerated Weathering.

4-6.1 Either of the following alternative Accelerated Weathering Conditioning procedures shall be used.

4-6.2 Alternative Procedure No. 1.

4-6.2.1 Apparatus.

(a) The apparatus shall consist of a vertical metal cylinder fitted with a vertical carbon arc at its center and having a specimen holder mounted within.

(b) The diameter of the cylinder shall be such that the distance to the face of the specimen holder from the center of the carbon arc is 14¾ inches.

(c) The cylinder shall be arranged to rotate about the arc at a rate of approximately three revolutions per minute.

(d) A water spray shall be provided within the cylinder and fitted with means to regulate the amount of water discharged.

(e) The vertical carbon arc shall be either 0.5 inches diameter solid electrode type, if operating on direct current, or a single-cored electrode, if operating on alternating current. The electrodes shall be of uniform composition.

(f) The arc shall be surrounded by a clear globe of No. 9200 PX Pyrex glass, 0.0625 inches thick, or other

enclosure having equivalent absorbing and transmitting properties.

4-6.2.2 Operation of the Test Equipment.

(a) The specimens for test shall be mounted on the inside of the cylinder facing the arc.

(b) The cylinder shall rotate at approximately three revolutions per minute for the duration of the test.

(c) The water spray shall discharge about 0.7 gallons per minute onto the specimens for about one minute during each revolution.

(d) The arc shall operate on 13 amperes direct current or 17 amperes, 60 hertz alternating current, with voltage at the arc of 140 volts.

(e) The electrodes shall be renewed at intervals sufficiently frequent to insure full operative conditions of the lamp.

(f) The globe shall be cleaned when the electrodes are removed or at least once in each 36 hours of operation.

4-6.2.3 Test Cycle.

(a) Specimens shall be subjected to this exposure for 360 hours.

(b) Specimens shall then be allowed to dry thoroughly at a temperature between 70 and 100 degrees Fahrenheit.

(c) After drying, the specimens shall proceed through the Flame Test.

4-6.3 Alternative Procedure No. 2.

4-6.3.1 Apparatus.

(a) The apparatus shall consist of a vertical carbon arc mounted at the center of a vertical cylinder.

(b) A rotating rack shall be mounted on the inside of the cylinder such that the distance from the face of the specimen to the center of the arc is 18¾ inches.

(c) The arc shall be designed to accommodate two pairs of carbon: No. 22 upper electrodes and No. 13 lower electrodes. However, the arc shall burn between only one pair of electrodes at a time.

(d) No filters or enclosures shall be used between the arcs and the specimens.

(e) Spray nozzles shall be mounted in the cylinder so that the specimens shall be exposed to wetting once during each revolution of the track.

4-6.3.2 Operation of Test Equipment.

(a) The specimens for test shall be mounted on the rotating rack, facing the arc.

(b) The rack shall rotate about the arc at a uniform speed of about one revolution in two hours.

(c) The arc shall operate on 60 amperes and 50 volts across the arc for alternating current or 50 amperes and 60 volts across the arc for direct current.

4-6.3.3 Test Cycle.

(a) Specimens shall be subjected to this exposure for 100 hours.

(b) They shall then be allowed to dry thoroughly at a temperature between 70 and 100 degrees Fahrenheit.

(c) After drying, the specimens shall proceed through the Flame Test.

Chapter 5 Flame Resistance Requirements

5-1 Small-Scale Test.

5-1.1 When subjected to the small-scale test described in Section 3-1 no specimen shall continue flaming for more than two seconds after the test flame is removed from contact with the specimen.

5-1.2 The vertical spread of flame and afterglow (smoldering combustion) on the material, as indicated by the length of char or the measurement from the bottom of the sample above which all material is sound and in original condition, shall not exceed the values shown in Table 5-1.

5-1.3 At no time during or after the application of the test flame shall portions or residues of textiles or films which break or drip from any test specimen continue to flame after they reach the floor of the tester.

5-1.4 There are some synthetic fabrics that are made of inherently flame-retardant fibers or having flame-retardant treatment that will not meet the requirements of the small-scale test due to the restrictive nature of the specimen holder. When this occurs, the fabric should be evaluated by means of the large-scale test.

Table 5-1
Permissible Length of Char or Destroyed Material — Small-Scale Test

Weight of Treated Fabric Being Tested	Maximum Average Length of Char or Destroyed Material for Ten Specimens	Maximum Length of Char or Destroyed Material for Any Specimen
Ounces per Square Yard	Inches	Inches
Over 10	3½	4½
Over 6 and not exceeding 10	4½	5½
Not exceeding 6	5½	6½

5-2 Large-Scale Test.

5-2.1 When subjected to the large-scale test described in Section 3-2, no specimen, in single sheets or in folds, shall continue flaming for more than two seconds after the test flame is removed from contact with the specimen.

5-2.2 The vertical spread of burning on the material in single sheets shall not exceed 10 inches above the tip of the test flame. This vertical spread shall be measured as the distance from the tip of the test flame to a horizontal line above which all material is sound and in original condition, except for possible smoke deposits.

5-2.3 The vertical spread of burning on the folded specimens shall not exceed 35 inches above the tip of the test flame, but the afterglow may spread in the folds.

5-2.4 At not time during or after the application of the test flame shall any portions or residues of textiles or films which break or drip from the test specimen continue to flame after they reach the floor of the tester.

Chapter 6 Field Test: Match Flame Test¹

6-1 Test Materials.

6-1.1 Test specimens shall be dry and shall be a minimum 1½ inches wide by 4 inches long.

6-1.2 The fire exposure shall be the flame from a common wood kitchen match (approximate length — 2⅞ inches; approximate weight — 29 grams per hundred), which is reasonably equivalent to that of a standard small-scale test described in Section 3-3, applied for 12 seconds.

6-2 Test Method.

6-2.1 The test shall be performed in a draft-free and safe location.

6-2.2 The sample shall be suspended (preferably held with a spring clip, tongs or some similar device) with the long axis vertical, with the flame applied to the center of the bottom edge, and the bottom edge ½ inch above the bottom of the flame.

6-2.3 After 12 seconds of exposure, the match is to be removed gently away from the sample.

6-3 Test Requirements.

6-3.1 During the exposure, flaming shall not spread over the complete length of the sample or in excess of 4 inches from the bottom of the sample (for larger size samples).

6-3.2 There shall be not more than two seconds of afterflame.

6-3.3 Materials which break and drip flaming particles shall be rejected if the materials continue to burn after they reach the floor.

Appendix A Field Test

This Appendix is not a part of this NFPA Standard but is included for information purposes only.

A-1 General.

A-1-1 Field tests for flame resistance — what are they or what should they be, what do they mean, how depend-

¹ For discussion of limitations and interpretations of results of this field test, see Appendix A.

able are they? These are complex and controversial questions, and the answers can vary considerably depending upon many factors and circumstances. If field tests are to be used as part of a regulatory program, it is vitally important that their function and validity be understood.

A-1-2 With rare exceptions, small-scale field tests leave something to be desired, and cannot be as good or as reliable as formal laboratory tests. Therefore, it is strongly recommended that, whenever possible, tests should be performed strictly in accordance with the requirements of Section 3-1 for the laboratory test. The greatest deficiency in field tests is that in most instances the size and number of samples which can be taken for test are very limited. In the context of this field test, the test flame can be subject to much variation, and a completely draft-free location for testing is seldom available.

A-2 Applications/Specific Limitations.

A-2-1 Field testing is most useful and meaningful for confirmatory purposes, as just one part of a regulatory program which gives the authority having jurisdiction control over the installation of fabrics and other decorative materials. In other words, a field test should be primarily to verify that a material is probably what it has been reported to be. The field test has much less value when the authority having jurisdiction has no supplementary information about what is being tested and therefore is forced to rely solely on the field test findings.

A-2-2 There are only two types of decorative materials for which field tests can be deemed to provide foolproof and totally adequate results: those made entirely of non-combustible inorganic material, and those which ignite and burn readily on exposure to small flame. For example, with only a little experience an inspector will have no difficulty in identifying an all-glass fabric by means of a very small-scale test, and nothing more is necessary. The only effect of a small fire exposure on a glass fabric is to burn off the surface coloring, if any, leaving the threads themselves virtually undamaged. This result is not obtained with any other type of decorative fabric and it is readily recognized. At the other extreme, if a material ignites and burns readily with a very small-scale test, showing no semblance of flame resistance, again, nothing more is necessary since the material obviously is not acceptable.

A-2-3 Between these two extremes, field tests have a limited and a varying degree of reliability. In this large group, comprising the great majority of materials the inspector is likely to encounter in the field, the most reliable results will be obtained in the testing of cellulose-based materials (cotton, rayon, and paper) flame-retardant treated with the common inorganic salt formulations such as those listed in Appendix B-4. These materials retain their shape reasonably during testing, and the results are not greatly affected by differences in sample size or severity of fire exposure. On the other hand, the least reliable results are obtained with chemically treated fabrics of synthetic fibers, or flexible plastic films and laminates. These materials are subject to a variety of physical changes when exposed to fire, such as shrinking, curling, melting, elongating and similar distortions,

making the testing of small samples quite difficult and the results ambiguous. Furthermore, some of these thermo-plastic materials are apt to appear flame resistant with small flame exposures, but ignite and burn fiercely with larger and larger exposures.

A-3 Number of Samples.

A-3-1 Probably the most difficult and controversial question relates to the minimum number of samples which should be tested. The answer must be dictated by a number of factors, and certainly a good general rule would be the more samples, the better; but, in all cases, the inspector must be governed by exercising good judgment. The variety of circumstances which can be encountered is perhaps best illustrated by some specific examples:

(a) A dance in a school gymnasium, student-decorated with a profusion of paper banners, crepe paper streamers, figures made of pieces of tissue paper stuffed in chicken wire molds, hay and straw, painted fabrics, dry palm fronds and you-name-it, all supposed to be flame resistant: In this situation, the inspector has neither reason nor excuse to be inhibited in his taking of samples for tests. The materials are inexpensive, more than likely are not intended to be reused, and the taking of samples for tests will cause little if any damage to the decorative effect.

(b) A large assembly tent made of supposedly treated canvas but with no identifying marks and no confirming evidence of such treatment: The life hazard is acute, tent canvas can readily be patched, and therefore, the situation calls for nothing less than the taking of sufficient samples from all sections of canvas for the inspector to be satisfied that the quality and uniformity of the treatment are acceptable.

(c) A nightclub with very expensive draperies known to be adequately flame-retardant treated when installed two years ago: Is the quality of flame resistance still acceptable? The only way to be sure is to take a sample, but this is where, in the interest of maintaining good public relations, the inspector must be very diplomatic and very persuasive. Almost always, a place can be found where a small sample, hopefully large enough, can be extracted without causing any readily visible damage, and often this is all the inspector can hope to get.

A-4 Other Technical Complications.

A-4-1 There can be other complications of a technical nature. Decorative fabrics sometimes are installed overhead, in or near a horizontal position. Some plastic films or fabrics woven of thermoplastic synthetic fibers will successfully resist continued burning in the normal vertical position of test, but will exhibit continued burning if exposed in a horizontal position. It seems reasonable to assume that fabrics installed horizontally overhead are a more serious potential threat to fire safety than in the case of vertical hangings, and, therefore, the inspector is justified in taking stricter measures, including testing of such fabrics in a horizontal position.

A-4-2 A somewhat similar problem can exist with some of the new and increasingly popular decorative fabrics with one or more types of fibers in the threads along the

length (warp) and different fibers in the threads along the widths (fill). This can result in a different burning behavior in the two directions of the fabric, to the extent that where a flame-retardant treatment has been applied, tests for flame resistance in one direction may be acceptable, but the fabric could show continued burning in the other direction. Where visual examination of the fabric indicates this condition might exist, the inspector should test samples cut with the long dimension paralleling both the length and width of the fabric.

A-5 Experience of Inspector/Accuracy of Method.

A-5-1 By far the greatest benefit can be derived from field tests when the inspector has had the opportunity to practice and experiment on a variety of decorative materials, and particularly make comparisons between the results of more formal laboratory tests and the less precise field tests. Here, too, experience is the best teacher, and it is strongly recommended that inspectors who may be involved in this activity familiarize themselves with a wide variety of treated and inherently flame-resistant fabrics of many types, and their typical behavior under a variety of test conditions. With this background, the inspector is much more capable of properly interpreting field tests results.

A-5-2 The deficiencies and limitations of field tests can lead to misleading or erroneous results, and the error can be in both directions. It is quite possible to have a too-small sample show several seconds of afterflaming and the material be rejected, when full-scale tests would show it to conform. This, of course, is unfair to the owner, but at least the error is in the direction of safety. Unfortunately, it is equally possible for improper or inadequate field testing to indicate satisfactory flame resistance, whereas formal testing would show an unacceptable degree of flame resistance. Obviously, this can be a dangerous error.

A-6 Summary.

A-6-1 Field testing certainly is better than nothing, but it must be used with good judgment and its limitations recognized.

A-6-2 Field testing must not be relied upon as the sole means for insuring adequate flame resistance of decorative materials but is useful to augment a comprehensive regulatory program.

Appendix B Flame-Resistance Treatments

This Appendix is not a part of this NFPA Standard but is included for information purposes only.

B-1 General.

B-1-1 Hundreds of different chemicals have been used or tested for flame-retarding fabrics. Many proved reasonably effective flame retardants, but only a few are