

SIXTH EDITION

---

# FUNDAMENTALS OF DIGITAL LOGIC AND MICROCONTROLLERS

---

M. RAFIUZZAMAN

WILEY

# **Fundamentals of Digital Logic and Microcontrollers**

Sixth Edition

**M. RAFIUZZAMAN, Ph.D.**

Professor

California State Polytechnic University, Pomona

and

President

Rafi Systems, Inc.

**WILEY**

Copyright © 2014 by John Wiley & Sons, Inc. All rights reserved.

Published by John Wiley & Sons, Inc., Hoboken, New Jersey.  
Published simultaneously in Canada.

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, scanning or otherwise, except as permitted under Section 107 or 108 of the 1976 United States Copyright Act, without either the prior written permission of the Publisher, or authorization through payment of the appropriate per-copy fee to the Copyright Clearance Center, Inc., 222 Rosewood Drive, Danvers, MA 01923, (978) 750-8400, fax (978) 646-8600, or on the web at [www.copyright.com](http://www.copyright.com). Requests to the Publisher for permission should be addressed to the Permissions Department, John Wiley & Sons, Inc., 111 River Street, Hoboken, NJ 07030, (201) 748-6011, fax (201) 748-6008, or online at <http://www.wiley.com/go/permissions>.

**Limit of Liability/Disclaimer of Warranty:** While the publisher and author have used their best efforts in preparing this book, they make no representation or warranties with respect to the accuracy or completeness of the contents of this book and specifically disclaim any implied warranties of merchantability or fitness for a particular purpose. No warranty may be created or extended by sales representatives or written sales materials. The advice and strategies contained herein may not be suitable for your situation. You should consult with a professional where appropriate. Neither the publisher nor author shall be liable for any loss of profit or any other commercial damages, including but not limited to special, incidental, consequential, or other damages.

For general information on our other products and services or for technical support, please contact our Customer Care Department within the United States at (800) 762-2974, outside the U.S. at (317) 572-3993 or fax (317) 572-4002.

Wiley also publishes its books in a variety of electronic formats. Some content that appears in print may not be available in electronic formats. For more information about Wiley products, visit our web site at [www.wiley.com](http://www.wiley.com)

***Library of Congress Cataloging-in-Publication Data:***

Rafiquzzaman, Mohamed.

[Fundamentals of digital logic and microcomputer design]

Fundamentals of digital logic and microcontrollers / M. Rafiquzzaman. – Sixth edition.

pages cm

Revised edition of: Fundamentals of digital logic and microcomputer design.

Includes index.

ISBN 978-1-118-85579-9 (cloth)

1. Logic circuits. 2. Microcomputers—Design and construction. 3. Electronic digital computers—Circuits.

I. Title.

TK7888.4.R34 2014

621.39'5-dc23

2014017642

Printed in the United States of America.

10 9 8 7 6 5 4 3 2 1

# PREFACE

---

The fifth edition of the book covered basics of computer engineering and science from digital logic to the design of a complete microcomputer system using Intel 8086 and Motorola 68000. With the growing popularity of microcontrollers, it is now necessary to have a clear understanding of the basic principles of microcontrollers at the undergraduate level. Microcontrollers play an important role in the design of digital systems. They are found in a wide range of applications including office automation systems such as copiers and fax machines, consumer electronics such as microwave ovens, digital instruments, and robotics.

Hence, a typical microcontroller such as Microchip Technology's PIC18F is used to replace the 8086 and 68000 in this edition. Several PIC18F-based simple practical applications using C-language are provided. The sixth edition covers an enhanced version of both combinational and sequential logic design, basics of computer organization and microcontrollers.

Like the fifth edition, emphasis is given on the basic concepts. To cite an example, we clearly point out that computers understand only 0's and 1's. It is, therefore, important that students be familiar with binary numbers. Furthermore, we focus on the fact that computers can normally only add. Hence, all other arithmetic operations such as subtraction are performed via addition. This can be accomplished using two's-complement arithmetic for binary numbers. This topic is, therefore, also included along with a clear explanation of signed and unsigned binary numbers. Basic concepts such as this are illustrated with simple examples throughout this edition.

As in the previous edition, three design levels are covered in this book: device level, logic level, and system level. Device-level design using simple devices such as transistors is included for typical logic gates such as NOT. Logic-level design is the technique in which logic gates are used; design of digital components such as an adder is provided. Finally, system-level applications are covered using a typical microcontroller such as the PIC18F.

Digital systems at the logic level are classified into two types of circuits: combinational and sequential. Combinational circuits have no memory whereas sequential circuits contain memory. Microcontrollers are designed using both combinational and sequential circuits. Therefore, these topics are covered in detail.

This edition of the book contains more details for synthesizing digital logic circuits using a popular hardware description language such as Verilog. An overview of contemporary digital circuit implementation using a popular programmable logic device (PLD) such as field programmable gate array (FPGA) along with the CAD (computer aided design) tools is included.

Several chapters in the previous edition containing digital logic design have been retained and even strengthened in this edition. A few chapters of this new edition are written to present the fundamental concepts of C language programming and interfacing techniques associated with Microchip Technology's PIC18F4321 microcontroller. The PIC18F family continues to be popular. The PIC18F family is an excellent educational tool for acquiring an understanding of both hardware and software aspects of typical microcontrollers.

Several PIC18F-based simple practical applications using C-language are provided. Most of the examples are implemented successfully in the laboratory. In summary, the sixth edition covers an enhanced version of both combinational and sequential logic, basics of computer organization, and microcontrollers. The following major changes have been provided in this edition:

- Revised Chapters 1 through 5 of the fifth edition to update and strengthen certain topics on both combinational and sequential circuits. Several new examples are included. In addition, certain topics such as timing diagrams, hazards, stability, and Verilog and FPGA are enhanced.
- Chapter 6 of this edition contains design of the CPU, memory, and I/O. Design of both hardwired and microprogrammed CPU is included.
- Chapters 7 through 9 of this edition include microcontroller basics and PIC18F-based applications using C.

In this edition, the book is divided into nine chapters as follow:

Chapter 1 presents an explanation of basic terminologies, fundamental concepts of digital integrated circuits using transistors; a comparison of LSTTL, HC, and HCT IC characteristics, evolution of the microcontroller, and technological forecasts.

Chapter 2 includes various number systems and codes suitable for representing information in typical digital systems.

Chapter 3 covers Boolean algebra along with k-map simplification of Boolean functions. Several examples are included. The basic characteristics of digital logic gates are also presented.

Chapter 4 presents the analysis and design of combinational circuits. Typical combinational circuits such as adder, decoder, encoder, multiplexer, demultiplexer, and ROMs are included. An introduction to PLDs and FPGA is provided. Synthesis of combinational logic design using Verilog is also included.

Chapter 5 covers various types of flip-flops. Analysis and design of sequential circuits such as counters and registers are covered. An overview of topics such as flip-flop set-up time, hold time, and metastability is provided. Finally, synthesis of sequential logic design using Verilog is included.

Chapter 6 introduces basic concepts associated with CPU, memory, and I/O. It also covers the design of CPU including registers, ALU, and the control unit.

Chapter 7 presents basics of microcontroller including organization, memory, I/O, and C programming concepts.

Chapter 8 provides typical C programs which include I/O examples with LEDs and switches. PIC18F-based programmed and interrupt I/O using C are covered in a simplified manner.

Chapter 9 contains simple PIC18F-based applications using C. These include A/D and D/A converters, LCD displays, on-chip timers, DC voltmeter, and motor control using PWM (pulse width modulation).

The book can easily be adopted as a text for “digital logic design” and/or “introduction to microcontrollers” at the undergraduate level in electrical/computer engineering and computer science. The book introduces microcontroller hardware and software to form a bridge between digital logic and an advanced follow-up course in microcontrollers. The book provides an introduction to one of today’s popular microcontrollers, the PIC18F family. Although no advanced mathematical background is required, a basic course on DC circuits is required. A first course in C language programming is essential. Since C language programming is prerequisite for the course on microcontrollers, I/O and interfacing using C is included in this book. The audience for this book can also be practicing engineers and scientists in the industry. Practitioners of digital system design in the industry will find more simplified explanations, together with examples and comparison considerations, than are found in manufacturers’ manuals.

The author is especially indebted to his colleague, Dr. R. Chandra, of California State Polytechnic University, Pomona for reviewing the manuscript. The author is also grateful to his students Robert Benenyan, Michael Hachache, Cameron Chitsaz, Gagneet Bhatia, Luke Stankiewicz, and others for making constructive suggestions and to CJ Media of California for preparing the final version of the manuscript. Finally, the author is indebted to his deceased parents, who were primarily responsible for his accomplishments.

M. RAFIQUZZAMAN \*  
*Pomona, California*

# CONTENTS

---

<b>PREFACE</b>	<b>xiii</b>
<b>1: INTRODUCTION TO DIGITAL SYSTEMS</b>	<b>1</b>
1.1 Explanation of Terms	2
1.2 Design Levels	6
1.3 Combinational and Sequential Circuits	7
1.4 Digital Integrated Circuits	7
1.4.1 Diodes	7
1.4.2 Transistors	8
1.4.3 MOS Transistors	14
1.5 Integrated Circuits (ICs)	18
1.6 CAD (Computer-Aided Design)	19
1.7 Evolution of the Microcontroller	20
1.8 Typical Microcontroller Applications	21
1.8.1 A Simple Microcontroller Application	22
1.8.2 Embedded Controllers	23
<b>2: NUMBER SYSTEMS AND CODES</b>	<b>25</b>
2.1 Number Systems	25
2.1.1 General Number Representation	25
2.1.2 Converting Numbers from One Base to Another	28
2.2 Unsigned and Signed Binary Numbers	30
2.3 Codes	34
2.3.1 Binary-Coded-Decimal Code (8421 Code)	34
2.3.2 Alphanumeric Codes	35
2.3.3 Excess-3 Code	36
2.3.4 Gray Code	37
2.3.5 Unicode	39
2.4 Fixed-Point and Floating-Point Representations	40
2.5 Arithmetic Operations	41
2.5.1 Binary Arithmetic	41
2.5.2 BCD Arithmetic	51
2.6 Error Correction and Detection	53
Questions and Problems	55

<b>3: BOOLEAN ALGEBRA AND DIGITAL LOGIC GATES</b>	<b>59</b>
3.1 Basic Logic Operations	59
3.1.1 NOT Operation	59
3.1.2 OR operation	60
3.1.3 AND operation	62
3.2 Other Logic Operations	64
3.2.1 NOR operation	64
3.2.2 NAND operation	64
3.2.3 Exclusive-OR operation (XOR)	65
3.2.4 Exclusive-NOR Operation (XNOR)	66
3.3 IEEE Symbols for Logic Gates	67
3.4 Positive and Negative Logic	68
3.5 Boolean Algebra	69
3.5.1 Boolean Identities	70
3.5.2 Simplification Using Boolean Identities	72
3.5.3 Consensus Theorem	74
3.5.4 Complement of a Boolean Function	75
3.6 Standard Representations	76
3.7 Karnaugh Maps	80
3.7.1 Two-Variable K-map	81
3.7.2 Three-Variable K-map	82
3.7.3 Four-Variable K-map	85
3.7.4 Prime Implicants	87
3.7.5 Expressing a Boolean function in Product-of-sums (POS) form using a K-map	89
3.7.6 Don't Care Conditions	91
3.7.7 Five-Variable K-map	95
3.8 Quine–McCluskey Method	96
3.9 Implementation of Digital Circuits with NAND, NOR, and Exclusive-OR/Exclusive-NOR Gates	97
3.9.1 NAND Gate Implementation	98
3.9.2 NOR Gate Implementation	99
3.9.3 XOR / XNOR Implementations	102
Questions and Problems	106
 <b>4: COMBINATIONAL LOGIC</b>	 <b>109</b>
4.1 Basic Concepts	109
4.2 Analysis of a Combinational Logic Circuit	109
4.3 Design of a Combinational Circuit	110
4.4 Multiple-Output Combinational Circuits	112
4.5 Typical Combinational Circuits	114
4.5.1 Comparators	114
4.5.2 Decoders	118
4.5.3 Encoders	122
4.5.4 Multiplexers	127
4.5.5 Demultiplexers	129
4.5.6 Binary / BCD Adders and Binary Subtractors	129
4.6 IEEE Standard Symbols	136



4.7	Read-Only Memories (ROMs)	138
4.8	Programmable Logic Devices (PLDs)	140
4.9	Commercially Available Field Programmable Devices (FPDs)	144
4.10	HARDWARE DESCRIPTION LANGUAGE (HDL)	146
4.11	Verilog basics	148
4.11.1	Verilog keywords	148
4.11.2	A typical Verilog Segment	148
4.11.3	Verilog operators	151
4.11.4	Verilog Constants	152
4.11.5	Modeling logical conditions in a circuit	152
4.11.6	Verilog if-else and case-endcase structures	153
4.11.7	A typical Verilog Simulator	153
4.12	Verilog modeling examples for combinational circuits	155
4.12.1	Structural modeling	155
4.12.2	Dataflow modeling	161
4.12.3	Behavioral modeling	163
	Questions and Problems	168
<b>5:</b>	<b>SEQUENTIAL LOGIC</b>	<b>173</b>
5.1	Basic Concepts	173
5.2	Latches and Flip-Flops	173
5.2.1	SR Latch	174
5.2.2	Gated SR Latch	176
5.2.3	Gated D Latch	176
5.2.4	Edge-Triggered D Flip-Flop	177
5.2.5	JK Flip-Flop	180
5.2.6	T Flip-Flop	181
5.3	Flip-flop timing parameters for edge-triggered flip-flops	181
5.4	Preset and Clear Inputs	182
5.5	Summary of the gated SR latch and the Flip-Flops	182
5.6	Analysis of Synchronous Sequential Circuits	185
5.7	Types of Synchronous Sequential Circuits	188
5.8	Minimization of States	188
5.9	Design of Synchronous Sequential Circuits	190
5.10	Design of Counters	196
5.11	Examples of Synchronous Sequential Circuits	201
5.11.1	Registers	201
5.11.2	Modulo- $n$ Counters	203
5.11.3	Random-Access Memory (RAM)	206
5.12	Algorithmic State Machines (ASM) Chart	207
5.13	Asynchronous Sequential Circuits	214
5.14	Verilog description of typical synchronous sequential circuits	217
	Questions and Problems	235
<b>6:</b>	<b>CPU, MEMORY, AND I/O</b>	<b>243</b>
6.1	Design of the CPU	243
6.1.1	Register Design	244
6.1.2	Arithmetic Logic Unit (ALU)	244
6.1.3	ALU Design	255

6.1.4	Control Unit Design	257
6.2	Memory Organization	280
6.2.1	Types of Main memory	283
6.2.2	READ and WRITE Timing Diagrams	285
6.2.3	Main Memory Organization	287
6.3	Input/Output (I/O)	290
6.3.1	Simple I/O Devices	292
6.3.2	Programmed I/O	293
6.3.3	Interrupt I/O	295
6.4	CPU design using Verilog	296
	Questions and Problems	309
<b>7:</b>	<b>MICROCONTROLLER BASICS</b>	<b>317</b>
7.1	Basic Blocks of a Microcontroller	317
7.1.1	System Bus	318
7.1.2	Clock Signals	319
7.2	Microcontroller Architectures	320
7.3	Basic Concept of Pipelining	321
7.4	RISC vs. CISC	323
7.5	Functional Representation of a Typical RISC Microcontroller—The PIC18F4321	324
7.6	Basics of Programming Languages	324
7.6.1	Machine Language	326
7.6.2	Assembly Language	327
7.6.3	High-Level Language	327
7.7	Choosing a Programming Language	328
7.8	Introduction to C Language	329
7.8.1	Data Types	332
7.8.2	Bit Manipulation Operators	333
7.8.3	Control Structures	334
7.8.4	The switch Construct	338
7.8.5	The while Construct	338
7.8.6	The for Construct	340
7.8.7	The do-while Construct	341
7.8.8	Structures and Unions	341
7.8.9	Functions in C	342
7.8.10	Macros	343
	Questions and Problems	344
<b>8:</b>	<b>PIC18F HARDWARE AND INTERFACING USING C: PART 1</b>	<b>345</b>
8.1	PIC18F Pins and Signals	345
8.1.1	Clock	346
8.1.2	PIC18F Reset	350
8.1.3	A Simplified Setup for the PIC18F4321	350
8.2	PIC18F4321 programmed I/O using C	351
8.2.1	PIC 18F4321 I/O ports	351
8.2.2	Interfacing LEDs (Light Emitting Diodes) and Seven-segment Displays	354
8.2.3	Microchip MPLAB C18 compiler and the PICKit3 interface	355

8.2.4	Configuration commands	356
8.3	PIC18F Interrupts	359
8.3.1	PIC18F Interrupt Types	359
8.3.2	PIC18F External Interrupts in Default Mode	359
8.3.3	Interrupt Registers and Priorities	361
8.3.4	Setting the Triggering Levels of INTn Pin Interrupts	362
8.3.5	Programming the PIC18 interrupts using C	363
	Questions and Problems	369
<b>9:</b>	<b>PIC18F HARDWARE AND INTERFACING USING C: PART 2</b>	<b>373</b>
9.1	PIC18F Timers	373
9.1.1	Timer0	375
9.1.2	Timer1	378
9.1.3	Timer2	382
9.1.4	Timer3	384
9.2	PIC18F Interface to an LCD (Liquid Crystal Display)	390
9.3	Analog Interface	394
9.3.1	On-chip A/D Converter	395
9.3.2	Interfacing an External D/A (Digital-to-Analog) Converter to the PIC18F4321	403
9.4	Serial Interface	405
9.4.1	Synchronous Serial Data Transmission	405
9.4.2	Asynchronous Serial Data Transmission	405
9.4.3	PIC18F Serial I/O	406
9.5	PIC18F4321 Capture/Compare/PWM (CCP) Modules	413
9.5.1	CCP Registers	413
9.5.2	CCP Modules and Associated Timers	413
9.5.3	PIC18F4321 Capture Mode	413
9.5.4	PIC18F4321 Compare Mode	416
9.5.5	PIC18F4321 PWM (Pulse Width Modulation) Mode	417
9.6	DC Motor Control	419
	Questions and Problems	425
	<b>APPENDIX A: ANSWERS TO SELECTED PROBLEMS</b>	<b>429</b>
	<b>APPENDIX B: GLOSSARY</b>	<b>439</b>
	<b>APPENDIX C: TUTORIAL FOR COMPILING AND DEBUGGING A C-PROGRAM USING THE MPLAB</b>	<b>451</b>
	<b>APPENDIX D: INTERFACING THE PIC18F4321 TO A PERSONAL COMPUTER OR A LAPTOP USING PICKIT™ 3</b>	<b>479</b>
D.1	INITIAL HARDWARE SETUP FOR THE PIC18F4321	479
D.2	CONNECTING THE PERSONAL COMPUTER (PC) OR THE LAPTOP TO THE PIC18F4321 VIA PICKIT3	480
D.3	PROGRAMMING THE PIC18F4321 FROM A PERSONAL COMPUTER OR A LAPTOP USING THE PICKIT3	482
	<b>BIBLIOGRAPHY</b>	<b>485</b>
	<b>CREDITS</b>	<b>487</b>
	<b>INDEX</b>	<b>489</b>

# 1

## INTRODUCTION TO DIGITAL SYSTEMS

---

Digital systems are designed to store, process, and communicate information in digital form. They are found in a wide range of applications, including process control, communication systems, digital instruments, and consumer products. The digital computer, more commonly called the *computer*, is an example of a typical digital system.

A computer manipulates information in digital, or more precisely, binary form. A binary number has only two discrete values — zero or one. Each of these discrete values is represented by the OFF and ON status of an electronic switch called a *transistor*. All computers, therefore, only understand binary numbers. Any decimal number (base 10, with ten digits from 0 to 9) can be represented by a binary number (base 2, with digits 0 and 1).

The basic blocks of a computer are the central processing unit (CPU), the memory, and the input/output (I/O). The CPU of the computer is basically the same as the brain of a human. Computer memory is conceptually similar to human memory. A question asked to a human is analogous to entering a program into the computer using an input device such as the keyboard, and answering the question by the human is similar in concept to outputting the result required by the program to a computer output device such as the printer. The main difference is that human beings can think independently, whereas computers can only answer questions that they are programmed for. Computer hardware refers to components of a computer such as memory, CPU, transistors, nuts and bolts. Programs can perform a specific task such as addition if the computer has an electronic circuit capable of adding two numbers. Programmers cannot change these electronic circuits but can perform tasks on them using instructions.

Computer software, on the other hand, consists of a collection of programs. Programs contain instructions and data for performing a specific task. These programs, written using any programming language such as C, must be translated into binary prior to execution by the computer. This is because the computer only understands binary numbers. Therefore, a translator for converting such a program into binary is necessary. Hence, a translator program called the *compiler* is used for translating programs written in a programming language such as C into binary. These programs in binary form are then stored in the computer memory for execution because computers only understand 1's and 0's. Furthermore, computers can only add. This means that all operations such as subtraction, multiplication, and division are performed by addition.

Due to advances in semiconductor technology, it is possible to fabricate the CPU in a single chip. The result is the *microprocessor*. Both metal oxide semiconductor (MOS) and bipolar technologies were used in the fabrication process. The CPU can be placed on a single chip when MOS technology is used. However, several chips are

required with the bipolar technology. HCMOS (high speed complementary MOS) or BICMOS (combination of bipolar and HCMOS) technology (to be discussed later in this chapter) is normally used these days to fabricate the microprocessor in a single chip. Along with the microprocessor chip, appropriate memory and I/O chips can be used to design a *microcomputer*. The pins on each one of these chips can be connected to the proper lines on the system bus, which consists of address, data, and control lines. In the past, some manufacturers have designed a complete microcomputer on a single chip with limited capabilities. Single-chip microcomputers were used in a wide range of industrial and home applications.

“Microcontrollers” evolved from single-chip microcomputers. The microcontrollers are typically used for dedicated applications such as automotive systems, home appliances, and home entertainment systems. Typical microcontrollers, therefore, include a microcomputer, timers, and A/D (analog to digital) and D/A (digital to analog) converters — all in a single chip. Examples of typical microcontrollers are Intel 8751 (8-bit) / 8096 (16-bit) and Motorola/Freescale HC11 (8-bit) / HC16 (16-bit), and Microchip Technology PIC18F(8-bit)/PIC32(32-bit).

In this chapter, we first define some basic terms associated with the computers. We then describe briefly the evolution of the computers and the microcontrollers. Finally, a typical practical application, and technological forecasts are included.

## 1.1 Explanation of Terms

Before we go on, it is necessary to understand some basic terms (arranged in alphabetical order).

- *Address* is a pattern of 0's and 1's that represents a specific location in memory or a particular I/O device. An 8-bit microcontroller with 16 address bits can produce  $2^{16}$  unique 16-bit patterns from 0000000000000000 to 1111111111111111, representing 65,536 different address combinations (addresses 0 to 65,535).
- *Addressing mode* is the manner in which the microcontroller determines the operand (data) and destination addresses during execution of an instruction.
- *Arithmetic-logic unit* (ALU) is a digital circuit that performs arithmetic and logic operations on two  $n$ -bit digital words. Typical operations performed by an ALU are addition, subtraction, ANDing, ORing, and comparison of two  $n$ -bit digital words. The size of the ALU defines the size of the microcontroller. For example, an 8-bit microcontroller contains an 8-bit ALU.
- *Big endian* convention is used to store a 16-bit number such as 16-bit data in two bytes of memory locations as follows: the low memory address stores the high byte while the high memory address stores the low byte. The Motorola/Freescale HC11 8-bit microcontroller follows the big endian format.
- *Bit* is an abbreviation for the term *binary digit*. A binary digit can have only two values, which are represented by the symbols 0 and 1, whereas a decimal digit can have 10 values, represented by the symbols 0 through 9. The bit values are easily implemented in electronic and magnetic media by two-state devices whose states portray either of the binary digits 0 and 1. Examples of such two-state devices are a transistor that is conducting or not conducting, a capacitor that is charged or discharged, and a magnetic material that is magnetized north to south or south to north.

- *Bit size* refers to the number of bits that can be processed simultaneously by the basic arithmetic circuits of a microcontroller. A number of bits taken as a group in this manner is called a *word*. For example, an 8-bit microcontroller can process an 8-bit word. An 8-bit word is referred to as a *byte*, and a 4-bit word is known as a *nibble*.
- *Bus* consists of a number of conductors (wires) grouped to provide a means of communication among different elements in a microcontroller system. The conductors in a bus can be grouped in terms of their functions. A microcontroller normally has an address bus, a data bus, and a control bus. Address bits are sent to memory or to an external device on the *address bus*. Instructions from memory, and data to/from memory or external devices, normally travel on the *data bus*. Control signals such as read/write for the other buses and among system elements are transmitted on the *control bus*. Buses are sometimes *bidirectional*; that is, information can be transmitted in either direction on the bus, but normally in only one direction at a time.
- *Clock* is analogous to human heart beats. The microcontroller requires synchronization among its components, and this is provided by a *clock* or timing circuits.
- The *chip* is an integrated circuit (IC) package containing digital circuits.
- *CPU* (central processing unit) contains several registers (memory elements), an ALU, and a control unit. Note that the control unit translates instructions and performs the desired task. The number of peripheral devices depends on the particular application involved and may even vary within an application.
- *EEPROM* or *E<sup>2</sup>PROM* (electrically erasable programmable ROM) is nonvolatile. EEPROMs can be programmed without removing the chip from the socket. EEPROMs are called read most memories (RMMs) because they have much slower write times than read times. Therefore, these memories are usually suited for applications when mostly reading rather than writing is performed. An example of EEPROM is the 2864 (8K x 8).
- *EPROM* (erasable programmable ROM) is nonvolatile. EPROMs can be programmed and erased. The EPROM chip must be removed from the socket for programming. This memory is erased by exposing the chip to ultraviolet light via a lid or window on the chip. Typical erase times vary between 10 and 30 minutes. The EPROM is programmed by inserting the chip into a socket of the EPROM programmer, and providing proper addresses and voltage pulses at the appropriate pins of the chip. An example of EPROM is the 2764 (8K x 8).
- *Flash memory* is designed using a combination of EPROM and EEPROM technologies. Flash memory is nonvolatile and is invented by Toshiba in mid 1980s. Flash memory can be programmed electrically while embedded on the board. One can change multiple bytes at a time. An example of flash memory is the Intel 28F020 (256K x 8). Flash memory is typically used in cell phones and digital cameras.
- An *FPGA* (field programmable gate array) chip contains an array of digital logic blocks along with input and output blocks which can be connected together via programming using a hardware description language (HDL) such as Verilog or

VHDL. There are two types of components inside an FPGA. These are lookup table (stored in memory), and switch matrices. The concept of FPGA is based on the fact that a combinational circuit can be implemented using memory. In the past, digital logic circuits were built using all hardware (logic gates). It was a time-consuming task to debug the circuits. However, digital circuits implemented using FPGA's are faster to debug since they are programmable. Note that it is much faster to debug software than hardware. Hence, products can be developed using FPGA from conceptual design via prototype to production in a very short time. Therefore, use of FPGA in digital logic is very common these days.

- The term *gate* refers to digital circuits which perform logic operations such as AND, OR, and NOT. In an AND operation, the output of the AND gate is one if all inputs are one; the output is zero if one or more inputs are zero. The OR gate, on the other hand, provides a zero output if all inputs are zero; the output is one if one or more inputs are one. Finally, a NOT gate (also called an *inverter*) has one input and one output. The NOT gate produces one if the input is zero; the output is zero if the input is one.
- *Harvard architecture* is a type of CPU architecture which uses separate instruction and data memory units along with separate buses for instructions and data. This means that these processors can execute instructions and access data simultaneously. Processors designed with this architecture require four buses for program memory and data memory. These are one data bus for instructions, one address bus for addresses of instructions, one data bus for data, and one address bus for addresses of data. The sizes of the address and data buses for instructions may be different from the address and data buses for data. Several microcontrollers including the PIC18F are designed using the Harvard architecture. This is because it is inexpensive to implement these buses inside the chip since both program and data memories are internal to the chip.
- *Instruction set* of a microcontroller is a list of commands that the microcontroller is designed to execute. Typical instructions are ADD, SUBTRACT, and STORE. Individual instructions are coded as unique bit patterns which are recognized and executed by the microcontroller. If a microcontroller has three bits allocated to the representation of instructions, the microcontroller will recognize a maximum of  $2^3$ , or eight, different instructions. The microcontroller will then have a maximum of eight instructions in its instruction set. It is obvious that some instructions will be more suitable than others to a particular application. For example, in a control application, instructions inputting digitized signals to the processor and outputting digital control variables to external circuits are essential. The number of instructions necessary in an application will directly influence the amount of hardware in the chip set and the number and organization of the interconnecting bus lines.
- *Little endian* convention is used to store a 16-bit number such as 16-bit data in two bytes of memory locations as follows: the low memory address stores the low byte while the high memory address stores the high byte. The PIC18F microcontroller follows the little-endian format.
- *Microcomputer* typically consists of a microprocessor (CPU) chip, input and output chips, and memory chips in which programs (instructions and data) are stored.

- *Microcontroller* is implemented on a single chip containing a CPU, memory, and IOP (I/O and peripherals). Note that a typical IOP contains I/O unit of a microcomputer, timers, A/D (analog-to-digital) converter, analog comparators, serial I/O, and other peripheral functions (to be discussed later).
- *Microprocessor* is the CPU of a microcomputer contained in a single chip, and must be interfaced with peripheral support chips in order to function.
- *Pipelining* is a technique that overlaps instruction fetch (instruction read) with execution. This allows a microcontroller's processing operation to be broken down into several steps (dictated by the number of pipeline levels or stages) so that the individual step outputs can be handled by the microcontroller in parallel. Pipelining is often used to fetch the microcontroller's next instruction while executing the current instruction, which speeds up the overall operation of the microcontroller considerably. Microchip technology's PIC18F (8-bit microcontroller) uses a two-stage instruction pipeline in order to speed up instruction execution.
- *Program* contains instructions and data. Two conventions are used to store a 16-bit number such as 16-bit data in two bytes of memory locations. These are called *little endian* and *big endian byte ordering*. In little endian convention, the low memory address stores the low byte while the high memory address stores the high byte. For example, the 16-bit hexadecimal number, 2050 will be stored as two bytes in two 16-bit locations (Hex 5000 and Hex 5001) as follows: Address 5000 will contain 50 while address 5001 will store 20. In big endian convention, on the other hand, the low memory address stores the high byte while the high memory address stores the low byte. For example, the same 16-bit hexadecimal number, 2050 will be stored as two bytes in two 16-bit locations (Hex 5000 and Hex 5001) as follows: Address 5000 will contain 20 while address 5001 will store 50. Motorola / Freescale HC11 (8-bit microcontroller) follows big endian convention. Microchip PIC18F (8-bit microcontroller), on the other hand, follows the little endian format.
- *Random-access memory (RAM)* is a storage medium for groups of bits or words whose contents cannot only be read but can also be altered at specific addresses. A RAM normally provides *volatile storage*, which means that its contents are lost in case power is turned off. There are two types of RAM: static RAM (SRAM) and dynamic RAM (DRAM). *Static RAM* stores data in flip-flops. Therefore, this memory does not need to be refreshed. An example of SRAM is 6116 (2K  $\times$  8). *Dynamic RAM*, on the other hand, stores data in capacitors. That is, it can hold data for a few milliseconds. Hence, dynamic RAMs are refreshed typically by using external refresh circuitry. Dynamic RAMs (DRAMs) are used in applications requiring large memory. DRAMs have higher densities than static RAMs (SRAMs). Typical examples of DRAMs are the 4464 (64K  $\times$  4), 44256 (256K  $\times$  4), and 41000 (1M  $\times$  1). DRAMs are inexpensive, occupy less space, and dissipate less power than SRAMs.
- *Read-only memory (ROM)* is a storage medium for the groups of bits called *words*, and its contents cannot normally be altered once programmed. A typical ROM is fabricated on a chip and can store, for example, 2048 eight-bit words, which can be accessed individually by presenting to it one of 2048 addresses. This ROM is referred to as a *2K by 8-bit ROM*. 10110111 is an example of an 8-bit word that might be stored in one location in this memory. A ROM is a *nonvolatile storage*



device, which means that its contents are retained in case power is turned off. Because of this characteristic, ROMs are used to store permanent programs (instructions and data).

- *Reduced Instruction Set Computer (RISC)* contains a simple instruction set. In contrast, a *Complex Instruction Set Computer (CISC)* contains a large instruction set. The PIC18F is an RISC-based microcontroller while Motorola/Freescale HC11 is a CISC-based microcontroller.
- *Register* can be considered as volatile storage for a number of bits. These bits may be entered into the register simultaneously (in parallel) or sequentially (serially) from right to left or from left to right, 1-bit at a time. An 8-bit register storing the bits 11110000 is represented as follows:

1	1	1	1	0	0	0	0
---	---	---	---	---	---	---	---

- The *speed power product (SPP)* is a measure of performance of a logic gate. It is expressed in picojoules (pJ). SPP is obtained by multiplying the speed (ns) by the power dissipation (mW) of a gate.
- *Transistors* are basically electronic switching devices. There are two types of transistors. These are *bipolar junction transistors (BJTs)* and *metal-oxide semiconductor (MOS)* transistors. The operation of the BJT depends on the flow of two types of carriers: electrons (*n*-channel) and holes (*p*-channel), whereas the MOS transistor is unipolar and its operation depends on the flow of only one type of carrier, either electrons (*n*-channel) or holes (*p*-channel).
- *von Neumann (Princeton) architecture* uses a single memory unit and the same bus for accessing both instructions and data. Although CPUs designed using this architecture are slower compared to Harvard architecture since instructions and data cannot be accessed simultaneously because of the single bus, typical microprocessors such as the Pentium use this architecture. This is because memory units such as ROMs, EPROMs, and RAMs are external to the microprocessor. This will require almost half the number of wires on the mother board since address and data pins for only two buses rather than four buses (Harvard architecture) are required. This is the reason Harvard architecture would be very expensive if utilized in designing microprocessors. Note that microcontrollers using Harvard architecture internally will have to use von Neumann architecture externally. Texas Instrument's MSP 430 uses the von Neumann architecture.

## 1.2 Design Levels

Three design levels can be defined for digital systems: systems level, logic level, and device level.

- *Systems level* is the type of design in which CPU, memory, and I/O chips are interfaced to build a computer.
- *Logic level* is the design technique in which chips containing logic gates such as AND, OR, and NOT are used to design a digital component such as the ALU.
- Finally, *device level* utilizes transistors to design logic gates.